



**TANDY**  
**GRiD**

**3830 SL**  
(25-3573)

---

**1660**  
(GR1-3573)

**Service  
Manual**

## WARNING

### For UK

- Disconnect the mains plug from the supply socket when not in use.
- This equipment is not designed for connection to an IT power system.
- Care must be taken to ensure that the integrity of the PELV (Protective Extra Low Voltage) system is maintained when interfacing to other parts of equipment takes place.

This equipment is produced to BS800/1983.

### For the Netherlands

VOLDOET AAN EEC RIGHTLJN 82/499 E.E.C.

### For UK

## WARNING

This apparatus must be earthed for your safety.

To ensure safe operation three pin-plug (not for U.K.) must be inserted only into a standard three-pin power point which is effectively earthed through the normal household wiring.

Ensure the main outlet socket is easily accessible to enable the user to isolate the apparatus from the main supply by withdrawing the main plug.

Extension cords used with the equipment must be three-core and be correctly wired to provide connection to earth. Wrongly wired extension cords are major cause of fatalities.

The fact that the equipment operates satisfactorily does not imply that the power point is earthed and that the installation is completely safe.

For your safety, if any doubt about the effective earthing of the power point, consult a qualified electrician.

## IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

Green-and-Yellow: Earth

Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured marking identifying the terminals in your plug, produced as follows: The wire which is coloured GREEN-and- YELLOW must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol or coloured GREEN or GREEN-and-YELLOW.

The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured RED.

## VANADIUM LITHIUM BATTERY ⚠

### • CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacture.

Dispose of used batteries according to manufacturer's instruction.

IBM PC XT/AT and PS/2 are registered trademarks of International Business Machines Corporation.  
MS-DOS and QBasic are registered trademarks of Microsoft Corporation.

# Contents

1. System Overview .....	1-1
1.1 General Description .....	1-1
1.2 Specifications .....	1-1
1.3 Location of Controls and Components .....	1-5
1.4 Block Diagrams .....	1-9
• Power Logic Diagram .....	1-9
• System Logic Diagram .....	1-10
1.5 System Memory Map .....	1-12
1.6 I/O Address Map .....	1-13
1.7 Pin Configurations .....	1-17
2. Diagnostic Test .....	2-1
2.1 Outline of Diagnostic Test .....	2-1
2.2 Diagnostic Description .....	2-2
2.3 Error messages .....	2-9
2.4 Diagnostic Test Procedure .....	2-18
3. Troubleshooting .....	3-1
3.1 Troubleshooting (For Block Exchange) .....	3-1
3.2 Appearance of Disassembled Block Unit .....	3-14
4. Disassembly/Reassembly .....	4-1
• Removing Battery Pack .....	4-1
• Removing RAM Board .....	4-1
• Removing Modem Card .....	4-2
4.1 Top case .....	4-3
4.2 Keyboard .....	4-5
4.3 Main PCB (Upper) .....	4-5
4.4 Floppy Disk Drive (FDD) .....	4-6
4.5 Main PCB (Lower) .....	4-6
4.6 Hard Disk Drive (HDD) .....	4-7
4.7 LCD Unit .....	4-8
4.8 FL Lamp .....	4-12
4.9 Replacing Diffusion Sheet Ass'y .....	4-13
4.10 Track Ball .....	4-15
5. LCD Contrast Adjustment .....	5-1
6. Schematic Diagrams/Parts Location/Replacement Parts List .....	6-1
6.1 Wiring Connection Diagram .....	6-1
6.2 Schematic Diagrams .....	6-3
(1) Main PCB (Upper), CPU/Co-processor Circuit .....	6-3
(2) Main PCB (Upper), DRAM and Keyboard Interface Circuits .....	6-5
(3) Main PCB (Upper), VGA Circuit .....	6-7
(4) Main PCB (Upper), VRAM and Frame Memory Circuits .....	6-9
(5) Main PCB (Lower), FLASH Memory (BIOS) and I/O Subsystem Circuits .....	6-11
(6) Main PCB (Lower), Keyboard Controller and SKBE Circuits .....	6-13
(7) Main PCB (Lower), FDC, Parallel Port, and GA2 Circuits .....	6-15
(8) Main PCB (Lower), Power Control Circuit .....	6-17
(9) Main PCB (Lower), Connector Circuit .....	6-19
(10) Power/Battery LED PCB and LED/Switch PCB .....	6-21
6.3 Printed Circuit Board and Parts Location .....	6-23
Main PCB (Upper) .....	6-23
Main PCB (Lower) .....	6-25
Power/Battery LED PCB, LED/Switch PCB and Contrast Control PCB .....	6-27
6.4 Exploded View .....	6-29
6.5 Replacement Parts List (Mechanical, Accessories, Packing and Electrical) .....	6-31
6.6 Keyboard Parts Locations .....	6-40
6.7 Replacement Parts List (Keyboard) .....	6-41

# Safety Precaution

There are special components used in the computer which are important for safety. These parts are shaded on the schematic diagram and indicated by a safety mark  $\triangle$  on the replacement parts list. It is essential that these critical parts should be replaced with the manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without written permission of the manufacturer or this will void the original parts and labor guarantee.

## 1. System Overview

### 1.1 General Description

This computer is based on the 80386SL microprocessor and can run up to 25 MHz.

An 80387SX (or 80387SL) math co-processor socket is included.

The system supports up to 8 megabytes of RAM (Total); 2 megabytes are placed on the main logic board, and an additional 2 or 6 megabytes can be added using optional RAM board.

Both system BIOS and video BIOS can be in shadow RAM.

Without processor RAM cache, the system uses pagemode memory and/or interleaved memory to attain virtual zero-wait-state operation.

Standard ports include two serial (one of which is used mainly with a modem), one parallel, one VGA, one external mouse, and one external keyboard (IBM-PS/2-style mini DIN size).

The disk drives are a 2.5-inch 80 megabytes hard disk and a 3.5-inch 1.44 megabytes floppy disk drive.

The VGA interface is on the main logic board and it supports an analog monitor and a 640 x 480 black and white liquid crystal display. The track ball is included as a useful pointing device.

The AT bus port socket is present for optional docking unit.

### 1.2 Specifications

#### Main Unit

##### PROCESSOR

###### CPU

Microprocessor 80386SL, 25/12.5 MHz  
Co-processor (Option) 80387SX (or 80387SL), 25 MHz

##### Memory

###### RAM

2MB Standard, 64KB Cache SRAM (for GRiD 1660); 16KB Cache SRAM (for Tandy 3830 SL)  
Up to 8MB expandable using optional RAM Card

Total RAM	4 MB	8 MB
Type of RAM Card	2MB RAM Card	6MB RAM Card

##### ROM

128KB FLASH ROM with 32 pins PLCC type including VGA BIOS (not expandable)

##### Real Time Clock

256-byte CMOS RAM backed up by Vanadium Lithium Battery (rechargeable)  
RTC battery life time: Approx. 3 months

##### Internal slot

For dedicated MODEM

##### Storage

###### FDD

Floppy Disk 3 1/2" double sided, high density, double tracked  
Recording Capacity 1.44M/720K bytes

###### HDD

Hard Disk 2 1/2"  
Capacity 81.18MB (formatted)  
Transfer Rate 12M bits/sec (to/from media)  
Seek Time Average 19msec

<b>Display</b>										
<b>Type</b>	See-through type LCD (black character/white background, reversible) with FL backlight									
<b>Resolution</b>	640 × 480 dots 80 characters × 25 lines									
<b>Format</b>										
<b>Character</b>	80 columns × 25 lines 40 columns × 25 lines									
<b>Graphics</b>	640 × 480 dots									
<b>Aspect Ratio</b>	1.000 : 1.000									
<b>Gray Scale</b>	16 levels (64 levels only for mode 13)									
<b>Keyboard</b>										
<b>Number of keys</b>	84 External Keyboard (Optional PS/2-style)									
<b>Special Key</b>	Following combinations are supported by ROM-BIOS.									
<b>Combination</b>	Even if another keyboard interrupt driver is installed, these functions work except Fn+F2. Fn+F1: Turns LCD reversed mode On/Off or change color mapping Fn+Shift+F1: Reverses cyclic order of Fn+F1 Fn+F2: Changes display device (LCD/CRT/LCD & CRT simultaneously) Fn+F3: Changes CPU clock speed (High/Low speed) Fn+F4: Turns the hard disk drive motor Off Fn+F5: Turns speaker On/Off Fn+F6: Backlit brightness control (Low, Medium, High) Fn+F7: Turns LCD and backlight Off Fn+F8: Turns serial interface and modem Off Fn+F9: Does nothing Fn+F10: Turns system to full standby mode Fn+F11: Turns text expansion On/Off on LCD in text mode (Tandy 3830 SL only) Fn+F12: Changes Bi-level/Gray shades video on LCD in text mode (Tandy 3830 SL only) Fn: Numeric keypad Fn+Keypad: Lock numeric keypad									
<b>I/O</b>	Parallel Port DB-25 (female) Serial Port DB-9 (male) VGA Monitor Port DB-15 (female) AT-Bus Port 200pin (female)									
<b>Control</b>	Power Switch On/Off Contrast Reset Button									
<b>Resume Battery</b>										
<b>Type</b>	Rechargeable Vanadium Lithium battery									
<b>Nominal Voltage</b>	3 Volts									
<b>Nominal Capacity</b>	100 mAH (5 hour rating)									
<b>Duty Cycle</b>	Average 1000 times									
<b>Weight</b>	0.01 lbs × 2 (6.5g × 2)									
<b>LED Indicators</b>										
<b>Power/Speed</b>	<table border="1" style="border-collapse: collapse; width: 100%;"> <thead> <tr> <th style="border: none;">LED Color</th> <th style="border: none;">On</th> <th style="border: none;">Off</th> </tr> </thead> <tbody> <tr> <td style="border: none;">Green</td> <td style="border: none;">High speed operation</td> <td style="border: none;">Power off</td> </tr> <tr> <td style="border: none;">Orange</td> <td style="border: none;">Low speed operation</td> <td style="border: none;"></td> </tr> </tbody> </table>	LED Color	On	Off	Green	High speed operation	Power off	Orange	Low speed operation	
LED Color	On	Off								
Green	High speed operation	Power off								
Orange	Low speed operation									
<b>Battery</b>	<table border="1" style="border-collapse: collapse; width: 100%;"> <thead> <tr> <th style="border: none;">LED Color</th> <th style="border: none;"></th> </tr> </thead> <tbody> <tr> <td style="border: none;">Red</td> <td style="border: none;">Getting low battery*</td> </tr> <tr> <td style="border: none;">Orange</td> <td style="border: none;">Charging*</td> </tr> </tbody> </table>	LED Color		Red	Getting low battery*	Orange	Charging*			
LED Color										
Red	Getting low battery*									
Orange	Charging*									

\* Additionally orange blinking means that no battery is connected for charging, also red blinking indicates trouble with charging controller.

<b>Caps Lock (Shift Lock)*</b>	<b>LED Color</b>	<b>On</b>	<b>Off</b>
	Green	Caps (Shift) On	Caps (Shift) Off
<b>Scroll Lock</b>	Green	Scroll lock On	Scroll lock Off
<b>Num Lock</b>	Green	Numeric key On	Numeric key Off
<b>Key Pad</b>	Green	Keypad is enabled	
<b>HDD</b>	Green	HDD is operating	
<b>FDD</b>	Orange	FDD is operating	
<b>Warning Beep</b>			
<b>Type</b>	PIEZO		
<b>Battery Low Voltage</b>		When output voltage of battery becomes low, system begins beeping every 20 seconds during the last 2.5 minutes of battery life. Then system goes into the suspended/resume mode automatically, then resuming function is enabled.	
<b>Resuming Function</b>		<ul style="list-style-type: none"> <li>• Backup time with fully charged battery pack (Ni-MH): <ul style="list-style-type: none"> <li>Typ. 7 days (2MB DRAM)</li> <li>Typ. 5 days (8MB DRAM)</li> </ul> </li> <li>• Backup time with fully charged resume (Vanadium Lithium) battery: <ul style="list-style-type: none"> <li>Typ. 1 hour (2MB RAM)</li> <li>Typ. 1 hour (8MB RAM)</li> </ul> </li> </ul>	
<b>Software</b>			
<b>Operating System</b>		MS-DOS Ver. 5.0	
<b>EMS Driver Application Software</b>		LIM Ver. 4.0 compatible included in MS-DOS disk	
<b>Input Voltage</b>		QBASIC Ver. 1.0, Windows Version 3.1	
<b>Current Consumption</b>		22.8V	
<b>Temperature</b>		1.25A (Max.)	
<b>Operating Storage Humidity</b>		50°F to 100°F (10°C to 38°C)	
<b>Operating Storage Humidity</b>		-4°F to 150°F (-20°C to 60°C)	
<b>Weight</b>		Max. 80%	
<b>Dimensions (W x H x D)</b>		Max. 80%	
		5.9lbs (2.7kg)	
		11.7 x 1.7 x 8.7 inch (299 x 44 x 220mm)	

\*Note: For France and Belgium

## AC Adapter

<b>Primary</b>	110V–240Vac
<b>Secondary</b>	
<b>Voltage</b>	22.8Vdc at 0.88A 17Vdc at 1.25A
<b>Current Capacity</b>	1.25A (Max.)
<b>Operating Temperature</b>	32° F to 104° F (0°C to 40°C)
<b>Weight</b>	0.82lbs (0.37kg)
<b>Dimensions (W × H × D)</b>	2.5 × 1.5 × 5.7 inch (65 × 39.5 × 140mm)


## Battery Pack

<b>Type</b>	Rechargeable Ni-MH (Nickel-Metal Hydride) Battery
<b>Capacity</b>	1.45AH (5 hour rating) (Avg.) 14.4V (Avg.)
<b>Operating Time</b>	Approx. 3 hours under the following conditions: FL backlight (medium brightness): 90% on HDD operation: 10% FDD operation: 1%
<b>Charging Time</b>	Approx. 5 hours (Power On: at normal operation) (*Notes) Approx. 2 hours (Power Off)
<b>Duty Cycle</b>	Average 500 times
<b>Dimensions</b>	7.1 × 0.7 × 2.4 inch (181.2 × 19.5 × 61.2mm)
<b>Weight</b>	0.95lbs (430g)


**\*Notes** Power consuming condition (such as heavy FDD/HDD access) may cause longer charging time.  
Quick charging is done when the battery temperature is within approx. 4°C (40°F) to 50°C (122°F). Outside this range, no charging is done to prevent battery damage.

## 1.3 Location of Controls and Components

### ■ Front View



### ■ Bottom View



- 1. LCD Display
- 2. LCD CONTRAST Control

This control adjusts contrast of the LCD display relative to the viewing angle.

- 3. POWER Indicator

This green LED lights when the power switch is ON.  
 This indicator reflects the following CPU speed as well:  
 Lit orange: Slow (12.5MHz)  
 Lit green: Fast (25MHz)

- 4. BATTERY Indicator

The battery indicator reflects the following five conditions:

BATTERY Indicator Status	Battery Pack Status
BATTERY indicator not lit	The computer is being powered from the battery pack.
Lit orange	Quick charging
Lit green	Trickle charging
Lit red	Low battery pack power. The battery supply will last approximately 10 minutes after the BATTERY indicator glows red. The beeper sounds every 20 seconds during the last 2.5 minutes.
Blinking orange	The computer is being powered from the AC adapter and the battery pack is not attached.
Blinking red	Trouble has occurred in the battery charging controller, etc.

- 5. Click Buttons
- 6. Track Ball
- 7. Operation Indicators

When using the track ball, press the button to control the computer.  
 This is a pointing device that works like a mouse, except that you don't need a tabletop to roll it around on.  
 These indicators consist of HDD, Shift LK (Caps LK), Num LK, Scr LK, and Key Pad.


- 8. POWER Switch
- 9. Floppy Disk Drive
- 10. Eject Button
- 11. FDD Indicator
- 12. Keyboard
- 13. Rear Cover
- 14. Latch

Press this switch to turn the computer on/off.  
 Press this button to remove the floppy disk from the floppy disk drive. This lights when the computer reads from or writes to the floppy disk. The keyboard features 84 typewriter keys and special function keys. Swing this down to raise the back of the computer.  
 Used to hold the rear cover when the cover is used as a stand. Slide this to release the cover.


- 15. Modem Cover
- 16. Battery Release
- 17. Battery Pack Compartment
- 18. Hard Disk Drive Cover

Open this when you install or remove a modem.  
 To remove the battery pack, push the battery release in the direction indicated and slide the battery pack.  
 This houses the battery pack.  
 This covers the computer's hard disk drive.


■ Rear View



■ Right Side View



■ Left Side View



**18. RAM Board Slot Cover**

Open this to insert or remove a RAM board.

**19. VGA Monitor Port**

When using an external VGA monitor, connect it to this port with a monitor cable.

**20. Parallel Port**

Used to connect a printer.

**21. Serial Port**

Used to connect a serial device such as a mouse or modem.

**22. AT Bus Port**

Used to connect the optional docking unit, which is used for installing the expansion boards.

**23. Open Latch**

Slide the levers on both sides of the computer toward the front to open the display panel.

**24. RESET Button**

Use this button when releasing resume function or if there's no other way to restart the computer.

Use a narrow object, such as the tip of a ball-point pen to push the button. CAUTION: Do not use a pencil to push the button. Pencil lead can break off inside the computer and damage the computer's circuitry.

**25. External Keyboard Port**

When using an external keyboard (PS/2 type), connect its plug to this jack.

**26. External Mouse Port**

A PS/2 type mouse can be connected to this port.

**27. Modem Jack Cover**

Remove this only when connecting an internal modem card to this computer.

**28. DC IN Jack**

Connect the DC plug of the supplied AC Adapter.

**■ Attaching the Battery Pack**



First turn off the computer and disconnect the AC adapter.

Then turn the computer upside down.

Install the battery pack in the battery compartment at the underside of the computer, using the following procedure.

Attachment:

1. Insert the battery pack so that its end is aligned with the line marked in the battery pack compartment.
2. Slide the battery pack firmly until it locks in position.



**■ How to Remove the Track Ball for Cleaning**

Cautions:


- Do not use chemical solvents to clean the track ball.
- After you remove the track ball cover, do not touch any metal parts in the computer.

1. Insert the blade of a small, flat-blade screwdriver or a similar tool into the slot between the top left corner of the track ball cover and the computer. Then, carefully pry up and remove the cover from left to right.

Note: Be careful not to break the tabs on the cover.


2. Remove the track ball from the compartment.
3. Clean the track ball with soap and water. Then, rinse the track ball with water and thoroughly dry the track ball with a clean, soft cloth.
4. Replace the track ball and its cover.

Note: The track ball fits only one way.



# 1.4 Block Diagrams

## • Power Logic Diagram




- Notes:
- — Power Lines
  - — Control Lines
  - Refer to Sheet 8/10 for schematic diagram



## 1.5 System Memory Map

The Main Logic Board supports 128K bytes of ROM area using 1 piece 128K×8-bit ROM, and 2M bytes of RAM area using 4 pieces of 1M×4-bit RAM.

The 2MB of RAM area is expandable up to 8M bytes using an optional RAM Board in the RAM Slot.



## 1.6 I/O Address Map

### 1) System

Address	Function	IC No.
0H	DMA Channel 0 base and current address	IC3
1H	DMA Channel 0 base and word count	IC3
2H	DMA Channel 1 base and current address	IC3
3H	DMA Channel 1 base and word count	IC3
4H	DMA Channel 2 base and current address	IC3
5H	DMA Channel 2 base and word count	IC3
6H	DMA Channel 3 base and current address	IC3
7H	DMA Channel 3 base and word count	IC3
8H	Command register, DMA controller 1	IC3
9H	Request Register, DMA controller 1	IC3
0AH	Mask Register, DMA controller 1	IC3
0BH	Mode Register, DMA controller 1	IC3
0CH	Clear byte pointer, DMA controller 1	IC3
0DH	Master Clear, DMA controller 1	IC3
0DH	Temporary Register, DMA controller 1	IC3
0FH	Write all Mask Register Bits, DMA controller 1	IC3
0EH	Clear Mask Register, DMA controller 1	IC3
20H	Initialization Control Word ICW1, Interrupt Controller 1	IC3
21H	Initialization Control Word ICW2, Interrupt Controller 1	IC3
21H	Initialization Control Word ICW3, (Master Device) Interrupt Controller 1	IC3
21H	Initialization Control Word ICW3, (Slave Device) Interrupt Controller 1	IC3
21H	Initialization Control Word ICW4, Interrupt Controller 1	IC3
21H	Operation Control Word OCW1, Interrupt Controller 1	IC3
20H	Operation Control Word OCW2, Interrupt Controller 1	IC3
20H	Operation Control Word OCW3, Interrupt Controller 1	IC3
22H	CPU Power Mode Register	IC302
23H	Configuration Space Status Register	IC3
24H	Configuration Index Register	IC3
25H	Configuration Data Register	IC3
40H	Timer Counter 1 Channel 0 count	IC3
41H	Timer Counter 1 Channel 1 count	IC3
42H	Timer Counter 1 Channel 2 count	IC3
43H	Timer Counter 1 Command Register	IC3
48H	Timer Counter 2 Channel 0 count	IC3
4AH	Timer Counter 2 Channel 2 count	IC3
4BH	Timer Counter 2 Command Register	IC3
60H	Keyboard Controller data I/O input buffer	IC3
60H	Keyboard Controller data I/O output buffer	IC3
61H	Port 61	IC3
61H	Port 61	IC3
64H	Keyboard Controller Command	IC3

Address	Function	IC No.
64H	Keyboard Controller Status	IC3
70H	CMOS RAM Address port and NMI Mask	IC3
71H	RTC CMOS RAM data port	IC3
74H	Extended CMOS RAM address port (protected)	IC3
76H	Extended CMOS RAM data port (protected)	IC3
80H	Reserved	IC3
81H	DMA Memory Address Mapper Page Register Channel 2	IC3
82H	DMA Memory Address Mapper Page Register Channel 3	IC3
83H	DMA Memory Address Mapper Page Register Channel 1	IC3
84H	Reserved	IC3
85H	Reserved	IC3
86H	Reserved	IC3
87H	DMA Memory Address Mapper Page Register Channel 0	IC3
88H	Reserved	IC3
89H	DMA Memory Address Mapper Page Register Channel 6	IC3
8AH	DMA Memory Address Mapper Page Register Channel 7	IC3
8BH	DMA Memory Address Mapper Page Register Channel 5	IC3
8CH	Reserved	IC3
8DH	Reserved	IC3
8EH	Reserved	IC3
8FH	DMA Memory Address Mapper Page Register - Refresh	IC3
92H	Port 92	IC3
0A0H	Initialization Control Word ICW1, Interrupt Controller 2	IC3
0A1H	Initialization Control Word ICW2, Interrupt Controller 2	IC3
0A1H	Initialization Control Word ICW3, (Master Device) Interrupt Controller 2	IC3
0A1H	Initialization Control Word ICW3, (Slave Device) Interrupt Controller 2	IC3
0A1H	Initialization Control Word ICW4, Interrupt Controller 2	IC3
0A1H	Operation Control Word OCW1, Interrupt Controller 2	IC3
0A0H	Operation Control Word OCW2, Interrupt Controller 2	IC3
0A0H	Operation Control Word OCW3, Interrupt Controller 2	IC3
0C0H	DMA Channel 4 base and current address	IC3
0C2H	DMA Channel 4 base and current word count	IC3
0C4H	DMA Channel 5 base and current address	IC3
0C6H	DMA Channel 5 base and current word count	IC3
0C8H	DMA Channel 6 base and current address	IC3
0CAH	DMA Channel 6 base and current word count	IC3
0CCH	DMA Channel 7 base and current address	IC3
0CEH	DMA Channel 7 base and current word count	IC3
0D0H	Command register, DMA controller 2	IC3
0D0H	Status Register, DMA controller 2	IC3
0D2H	Request Register, DMA controller 2	IC3
0D4H	Mask Register, DMA controller 2	IC3
0D6H	Mode Register, DMA controller 2	IC3
0D8H	Clear byte pointer, DMA controller 2	IC3
0DAH	Master Clear, DMA controller 2	IC3
0DAH	Temporary Register, DMA controller 2	IC3


Address	Function	IC No.
0DCH	Clear Mask Register, DMA controller 2	IC3
0DEH	Write all Mask Register Bits, DMA controller 2	IC3
0EEH	Special Featuer Set Fast A20 Gate	IC3
0EFH	Special Featuer Set Fast CPU Reset	IC3
0F0H	MCP Register 0	IC303
0F4H	Slow CPU Register	IC302
0F5H	Fast CPU Register	IC302
0F9H	Special Feature Set Disable	IC3, IC302
0FBH	Special Feature Set Enable	IC3, IC302

## 2) Peripherals

Address	Function	IC No.
0102H	Parallel Port Configuration	IC3
278H	LPT2 Data Port	IC3
279H	LPT2 Status Port	IC3
27AH	LPT2 Control	IC3
27BH-27FH	Automatic data strobe registers	IC3
2F8H	Serial Controller Port B Receiver Buffer	IC3
2F8H	Serial Controller Port B Transmit holding Buffer	IC3
2F8H	Serial Controller Port B Divisor Latch Least Significant Byte	IC3
2F9H	Serial Controller Port B Divisor Latch Most Significant Byte	IC3
2F9H	Serial Controller Port B Interrupt Enable Register	IC3
2FAH	Serial Controller Port B Interrupt Id Register	IC3
2FBH	Serial Controller Port B Line Control Register	IC3
2FCH	Serial Controller Port B MODEM Control Register	IC3
2FDH	Serial Controller Port B Line Status Register	IC3
2FEH	Serial Controller Port B MODEM Status Register	IC3
2FFH	Serial Controller Port B Scratch Register	IC3
378H	LPT1 Data Port	IC3
379H	LPT1 Status	IC3
37AH	LPT1 Control	IC3
37BH-37FH	Automatic data strobe registers	IC3
3B4H	CRTC Index MP	IC314
3B5H	CRTC Data MP	IC314
3BCH	LPT3 Data Port	IC3
3BDH	LPT3 Status	IC3
3BEH	LPT3 Control	IC3
3C0H	Attribute Controller Index	IC314
3C1H	Attribute Controller Data in VGA	IC314
	Attribute Controller Data in EGA	
3C2H	Miscellaneous Output, Feature	IC314
3C3H	Motherboard Sleep Address	IC314
3C4H	Sequencer	IC314
3C5H	Sequencer	IC314
3C6H	RAMDAC Pixel Mask	IC314
3C7H	RAMDAC Address Register Read Mode	IC314
	RAMDAC Status Register	
3C8H	RAMDAC Address Register Write Mode	IC314

Address	Function	IC No.
3C9H	RAMDAC Data	IC314
3CAH	Feature Control	IC314
3CCH	Miscellaneous Output	IC314
3CEH	Graphic Controller and Extensions Index	IC314
3CFH	Graphic Controller and Extensions Data	IC314
3D4H	CRTC Index	IC314
3D5H	CRTC Data	IC314
3DAH	Feature Control, Display Status	IC314
3F0H	Floppy Disk Controller Port Status Register A	IC10
3F1H	Floppy Disk Controller Port Status Register B	IC10
3F2H	Floppy Disk Controller Digital Output Register	IC10
3F4H	Floppy Disk Controller Main Status Register	IC10
3F5H	Floppy Disk Controller Data Register	IC10
3F6H	Fixed Disk Register	IC10
3F7H	Floppy Disk Controller Digital Input Register	IC10
3F7H	Floppy Disk Controller Control Register	IC10
3F7H	Fixed Disk Decode	IC10
3F8H	Serial Controller Port A Receiver Buffer	IC3
3F8H	Serial Controller Port A Transmit holding Buffer	IC3
3F8H	Serial Controller Port A Divisor Latch Least Significant Byte	IC3
3F9H	Serial Controller Port A Divisor Latch Most Significant Byte	IC3
3F9H	Serial Controller Port A Interrupt Enable Register	IC3
3FAH	Serial Controller Port A Interrupt Id Register	IC3
3FBH	Serial Controller Port A Line Control Register	IC3
3FCH	Serial Controller Port A MODEM Control Register	IC3
3FDH	Serial Controller Port A Line Status Register	IC3
3FEH	Serial Controller Port A MODEM Status Register	IC3
3FFH	Serial Controller Port A Scratch Register	IC3
461H	Port 461 EISA Mode	IC3
46E8	AT Adapter Sleep Address	IC314

# 1.7 Pin Configurations



## Main PCB (UPPER)

### CN301 TRACK BALL Connector (4-pin)

Pin No.	Signal Name/Description	Direction
1	PDCLK	Out
2	PDDATA	In
3	GND	—
4	VCC	Out

### CN302 POWER/BATTERY LED PCB Connector (5-pin)


Pin No.	Signal Name/Description	Direction
1	PWRLED	Out
2	SPDLED	Out
3	BATLED	Out
4	CHGLED	Out
5	GND	—

### CN304 LED/SWITCH PCB Connector (7-pin)

Pin No.	Signal Name/Description	Direction
1	CAP	Out
2	NUM	Out
3	SCRL	Out
4	KEYPAD	Out
5	HDLUMP	Out
6	POWERSW	Out
7	GND	—

### CN306 MEMORY CARD Connector (50-pin)

Pin No.	Signal Name/Description	Direction	Pin No.	Signal Name/Description	Direction
1	VBB	Out	26	MD8	In/Out
2	GND	—	27	CASL1	Out
3	MAA0	Out	28	MD9	In/Out
4	MD0	In/Out	29	CASL2	Out
5	MAA1	Out	30	MD10	In/Out
6	MD1	In/Out	31	CASH1	Out
7	MAA2	Out	32	MD11	In/Out
8	MD2	In/Out	33	CASH2	Out
9	MAA3	Out	34	MD12	In/Out
10	MD3	In/Out	35	WLE	Out
11	MAA4	Out	36	MD13	In/Out
12	MD4	In/Out	37	WHE	Out
13	MAA5	Out	38	MD14	In/Out
14	MD5	In/Out	39	GND	—
15	MAA6	Out	40	MD15	In/Out
16	MD6	In/Out	41	RAS1	Out
17	MAA7	Out	42	CASL3	Out
18	MD7	In/Out	43	RAS2	Out
19	MAA8	Out	44	CASH3	Out
20	GND	—	45	VBB	Out
21	MAA9	Out	46	RAS3	Out
22	GND	—	47	GND	—
23	MAA10	Out	48	VBB	Out
24	VBB	Out	49	GND	—
25	GND	—	50	GND	—



Top View of Main PCB (Upper)

**CN308 LCD Connector (14-pin)**


Pin No.	Signal Name/ Description	Direction
1	S	Out
2	CP1	Out
3	CP2	Out
4	VDD	Out
5	VSS	Out
6	VEE	Out
7	DV0	Out
8	DV1	Out
9	DV2	Out
10	DV3	Out
11	DL0	Out
12	DL1	Out
13	DL2	Out
14	DL3	Out

**CN312 KEYBOARD Connector (20-pin)**

Pin No.	Signal Name/ Description	Direction
1	ww9	In
2	ww10	In
3	ww11	In
4	ww12	In
5	ww13	In
6	ww14	In
7	ww15	In
8	ww16	In
9	ww1	In
10	ww2	In
11	ww3	In
12	ww4	In
13	ww5	In
14	ww6	In
15	ww7	In
16	ww8	In
17	ww17	In
18	ww18	In
19	ww19	In
20	ww20	In

**CN309 LCD Connector (6-pin)**

Pin No.	Signal Name/ Description	Direction
1	VFL	Out
2	FLCONT	Out
3	FLVAR	Out
4	FLVSS	Out
5	CONLCD	Out
6	CONVAR	Out




**CN310 BEEPER Connector (2-pin)**

Pin No.	Signal Name/ Description	Direction
1	—	Out
2	—	Out

**CN303 PCB Connector (60-pin)**

Pin No.	Signal Name/ Description	Direction	Pin No.	Signal Name/ Description	Direction
1	GND	—	31	VBB	In
2	VCC	Out	32	VBB	In
3	VCC	Out	33	VBB	In
4	GREEN	Out	34	AGND	—
5	RED	Out	35	AGND	—
6	BLUE	Out	36	AGND	—
7	GND	—	37	GND	—
8	VSYNC	Out	38	HSYNC	Out
9	SUBLSYNC	In	39	VM	In
10	GAADB0	In/Out	40	GAADB1	In/Out
11	GAADB2	In/Out	41	GAADB3	In/Out
12	SUBLDATA	In	42	SUBLCLK	In
13	GACMD	In	43	GAOE	In
14	MEMW	In/Out	44	MEMR	In/Out
15	GAW	In	45	SROFF	In
16	HDD	In	46	COMX1	Out
17	NC	—	47	VGAAEN	In
18	GACK	In	48	RESETDRV	In
19	MEMCS16	In/Out	49	SBHE	In
20	IRQ9	Out	50	PDDATA	In/Out
21	GND	—	51	GND	—
22	CX1	Out	52	SPKR	In
23	GAIRQ	Out	53	CONLCD	In
24	LCDVEE	Out	54	POWERSW	Out
25	GND	—	55	GND	—
26	GND	—	56	GND	—
27	ROMCS0	Out	57	GND	—
28	IOR	In/Out	58	IOW	In/Out
29	F4	In	59	F18	In
30	HDLED	In	60	SMRAMCS	In


Bottom View of Main PCB (Upper)



CN305 PCB Connector (80-pin)

Pin No.	Signal Name/ Description	Direction	Pin No.	Signal Name/ Description	Direction
1	SA1	In/Out	41	SA0	In/Out
2	SA3	In/Out	42	SA2	In/Out
3	SA5	In/Out	43	SA4	In/Out
4	SA7	In/Out	44	SA6	In/Out
5	SA9	In/Out	45	SA8	In/Out
6	SA11	In/Out	46	SA10	In/Out
7	SA13	In/Out	47	SA12	In/Out
8	SA15	In/Out	48	SA14	In/Out
9	SA17	In/Out	49	SA16	In/Out
10	SA19	In/Out	50	SA18	In/Out
11	GND	—	51	GND	—
12	SD0	In/Out	52	SD1	In/Out
13	SD2	In/Out	53	SD3	In/Out
14	SD4	In/Out	54	SD5	In/Out
15	SD6	In/Out	55	SD7	In/Out
16	SD8	In/Out	56	SD9	In/Out
17	SD10	In/Out	57	SD11	In/Out
18	SD12	In/Out	58	SD13	In/Out
19	SD14	In/Out	59	SD15	In/Out
20	GND	—	60	GND	—
21	REFRESH	In	61	SYSCLK	Out
22	IOCHRDY	In/Out	62	PDCLK	In/Out
23	VGACS	In	63	IOCS16	In/Out
24	PWRGOOD	In	64	CHGLED	In
25	OWS	In	65	REFREQ	In
26	STPCLK	In	66	SMI	In
27	HALT	Out	67	INTA	Out
28	A20GATE	In	68	DMA8/16	In
29	LA17	In/Out	69	HLDA	Out
30	LA19	In/Out	70	LA18	In/Out
31	LA21	In/Out	71	LA20	In/Out
32	LA23	In/Out	72	LA22	In/Out
33	GND	—	73	GND	—
34	HRQ	In	74	INTR	In
35	NMI	In	75	CPURESET	In
36	MASTER	In	76	ERROR	Out
37	BALE	Out	77	SUSSTAT	In
38	LCDPWR	Out	78	BATLED	In
39	FLVAR	In	79	CONVAR	In
40	VDD	In	80	VLCD	In

Top View of Main PCB (Lower)



Main PCB (Lower)


CN1 OPTIONAL DOCKING UNIT Connector  
(200-pin)

Pin No.	Signal Name/ Description	Direction
1	EXT23V	In
2	EXT23V	In
3	GND	—
4	S2	Out
5	S1	Out
6	S3	In
7	S5	In
8	GND	—
9	BALE	Out
10	DRQ7	In
11	DRQ6	In
12	DRQ5	In
13	DRQ0	In
14	IRQ14	In
15	IRQ12	In
16	IRQ10	In
17	DACK2	Out
18	IRQ4	In
19	IRQ6	In
20	DRQ3	In
21	DRQ1	In
22	GND	—
23	HDCS0	Out
24	HD7	In/Out
25	GND	—
26	HD4	In/Out
27	HDLED	Out
28	IOCS16	Out
29	GND	—
30	SD0	In/Out
31	SD2	In/Out
32	SD4	In/Out
33	SD6	In/Out
34	SD8	In/Out
35	SD10	In/Out
36	SD12	In/Out
37	SD14	In/Out
38	GND	—
39	EXTKDATA	In/Out
40	EXTMCLK	In/Out
41	GND	—
42	EXT5V	In
43	EXT5V	In
44	EXT5V	In
45	EXT5V	In
46	GND	—
47	HSYNC1	Out
48	BGND	Out
49	RGND	Out
50	GGND	Out

(Continued)

**CN1 OPTIONAL DOCKING UNIT Connector (200-pin)**

Pin No.	Signal Name/ Description	Direction	Pin No.	Signal Name/ Description	Direction	Pin No.	Signal Name/ Description	Direction
51	GREEN	Out	101	DOCKING	In	151	GND	—
52	RED	Out	102	—	Out	152	GND	—
53	BLUE	Out	103	EX5VSW	Out	153	SUBLSYNC	Out
54	VSYNC1	Out	104	IOCHCK	In	154	SUBLDATA	Out
55	GND	—	105	SMEMR	Out	155	GND	—
56	EXT5V	In	106	SMEMW	Out	156	MEMCS16	Out
57	EXT5V	In	107	MEMW	In/Out	157	DRQ2	In
58	EXT5V	In	108	MEMR	In/Out	158	P13	Out
59	EXT5V	In	109	XD7	In/Out	159	SLCTIN	Out
60	GND	—	110	EXSYSCLK	Out	160	P12	Out
61	EXTMDATA	In/Out	111	GND	—	161	NC	—
62	EXTKCLK	In/Out	112	LA17	In/Out	162	LPTINIT	Out
63	GND	—	113	LA18	In/Out	163	P11	Out
64	SD15	In/Out	114	LA20	In/Out	164	P15	Out
65	SD13	In/Out	115	GND	—	165	P10	Out
66	SD11	In/Out	116	SA9	In/Out	166	LPTAFD	Out
67	SD9	In/Out	117	SA8	In/Out	167	LPTSTRD	Out
68	SD7	In/Out	118	SA7	In/Out	168	LPTD3	In/Out
69	SD5	In/Out	119	SA6	In/Out	169	LPTD2	In/Out
70	SD3	In/Out	120	SA5	In/Out	170	LPTD4	In/Out
71	SD1	In/Out	121	SA4	In/Out	171	LPDT1	In/Out
72	GND	—	122	SA3	In/Out	172	LPTD7	In/Out
73	AEN	Out	123	SA2	In/Out	173	LPTD0	In/Out
74	PDIAG	Out	124	SA1	In/Out	174	LPTD6	In/Out
75	EXTRST	Out	125	SA0	In/Out	175	GND	—
76	IOW	In/Out	126	GND	—	176	SA11	In/Out
77	IOR	In/Out	127	LPTD5	In/Out	177	SA10	In/Out
78	HDCS1	Out	128	GND	—	178	SA12	In/Out
79	GND	—	129	F28	Out	179	SA13	In/Out
80	IRQ7	In	130	F24	In	180	SA14	In/Out
81	DACK1	Out	131	F2	In	181	SA15	In/Out
82	DACK3	Out	132	F20	In	182	SA16	In/Out
83	IRQ5	In	133	F22	In	183	SA17	In/Out
84	IRQ3	In	134	F6	In	184	SA18	In/Out
85	GND	—	135	F11	Out	185	SA19	In/Out
86	IRQ11	In	136	CE2	In	186	GND	—
87	IRQ15	In	137	F27	Out	187	LA19	In/Out
88	DACK0	Out	138	F26	Out	188	LA21	In/Out
89	DACK5	Out	139	F16	Out	189	LA22	In/Out
90	DACK6	Out	140	F12	Out	190	LA23	In/Out
91	DACK7	Out	141	F18	Out	191	GND	—
92	MASTER	In	142	F14	Out	192	REFRESH	In/Out
93	IRQ9	In	143	F4	Out	193	IOCHRDY	In/Out
94	GND	—	144	TC	Out	194	OWS	Out
95	S6	In	145	SBHE	Out	195	EXTRTCAS	Out
96	S0	Out	146	GND	—	196	EXTRTCDS	Out
97	S4	In	147	POWERSW	Out	197	EXTRTCRW	Out
98	S7	In	148	SUBLCLK	Out	198	IRQ8	In
99	GND	—	149	—	Out	199	GND	—
100	EXT23V	In	150	DOCKING	In	200	GND	—



**CN2 OPTIONAL MODEM Connector (18-pin)**

Pin No.	Signal Name/Description	Direction
1	CT3	In
2	GND	—
3	DSR	In
4	VCC	Out
5	RSLD	In
6	SHUTDWN	Out
7	RI	In
8	RXD	In
9	SPKR	In
10	RTS	Out
11	DTR	Out
12	TXD	Out
13	RST	Out
14	GND	—
15	12V	Out
16	GND	—
17	-12V	—
18	GND	—

**CN4 PARALLEL PORT (25-pin)**


Pin No.	Signal Name/Description	Direction
1	STROBE	Out
2	D0	Out
3	D1	Out
4	D2	Out
5	D3	Out
6	D4	Out
7	D5	Out
8	D6	Out
9	D7	Out
10	LPTAK	In
11	LPTBUSY	In
12	LPTPE	In
13	SLCT	In
14	AFD	Out
15	ERROR	In
16	INIT	Out
17	SLCTIN	Out
18	GND	—
19	GND	—
20	GND	—
21	GND	—
22	GND	—
23	GND	—
24	GND	—
25	GND	—

**CN5 INTERNAL FDD Connector (26-pin)**

Pin No.	Signal Name/Description	Direction
1	VCC	Out
2	F2	In
3	VCC	Out
4	F4	In
5	VCC	Out
6	F6	Out
7	VCC	Out
8	NC	—
9	NC	—
10	F10	Out
11	F11	Out
12	F12	Out
13	GND	—
14	F14	Out
15	GND	—
16	F16	Out
17	GND	—
18	F18	Out
19	GND	—
20	F20	In
21	GND	—
22	F22	In
23	GND	—
24	F24	In
25	GND	—
26	F26	Out

**CN3 SERIAL PORT (9-pin)**

Pin No.	Signal Name/Description	Direction
1	CD	In
2	RD	In
3	TD	Out
4	DTR	Out
5	GND	—
6	DSR	In
7	RTS	Out
8	CTS	In
9	RI	In



**CN6 INTERNAL HDD Connector (44-pin)**


Pin No.	Signal Name/Description	Direction	Pin No.	Signal Name/Description	Direction
1	IORST	Out	23	IOW	Out
2	GND	—	24	GND	—
3	HD7	In/Out	25	IOR	Out
4	SD8	In/Out	26	GND	—
5	SD6	In/Out	27	NC	—
6	SD9	In/Out	28	NC	—
7	SD5	In/Out	29	NC	—
8	SD10	In/Out	30	GND	—
9	HD4	In/Out	31	IRQ14	In
10	SD11	In/Out	32	IOCS16	In
11	SD3	In/Out	33	SA1	Out
12	SD12	In/Out	34	PDIAG	In
13	SD2	In/Out	35	SA0	Out
14	SD13	In/Out	36	SA2	Out
15	SD1	In/Out	37	HDCS0	Out
16	SD14	In/Out	38	HDCS1	Out
17	SD0	In/Out	39	HDLED	In
18	SD15	In/Out	40	GND	—
19	GND	—	41	VCC	Out
20	NC	—	42	VCC	Out
21	NC	—	43	GND	—
22	GND	—	44	VCC	Out

**CN7 EXTERNAL KEYBOARD Connector (6-pin)**

Pin No.	Signal Name/Description	Direction
1	EXTKDATA	In/Out
2	NC	—
3	GND	—
4	VCC	Out
5	EXTKCLK	In/Out
6	NC	—

**CN8 EXTERNAL MOUSE Connector (6-pin)**



Pin No.	Signal Name/Description	Direction
1	EXTMDATA	In/Out
2	NC	—
3	GND	—
4	VCC	Out
5	EXTMCLK	In/Out
6	NC	—



**CN9 PCB Connector (60-pin)**

Pin No.	Signal Name/ Description	Direction	Pin No.	Signal Name/ Description	Direction
1	GND	—	31	VBB	Out
2	VCC	Out	32	VBB	Out
3	VCC	Out	33	VBB	Out
4	GREEN	In	34	GGND	—
5	RED	In	35	RGND	—
6	BLUE	In	36	BGND	—
7	GND	—	37	GND	—
8	VSYNC1	In	38	HSYC1	In
9	SUBLSYNC	Out	39	VM	Out
10	GAADB0	In/Out	40	GAADB1	In/Out
11	GAADB2	In/Out	41	GAADB3	In/Out
12	SUBLDATA	Out	42	SUBLCLK	Out
13	GACMD	Out	43	GAOE	Out
14	MEMW	In/Out	44	MEMR	In/Out
15	GAW	Out	45	SROFF	Out
16	HDD	Out	46	COMX1	In
17	NC	—	47	VGAAEN	Out
18	GACK	Out	48	RESETDRV	Out
19	MEMCS16	In/Out	49	SBHE	Out
20	IRQ9	In	50	PDDATA	In/Out
21	GND	—	51	GND	—
22	CX1	In	52	SPKR	Out
23	GAIRQ	In	53	CONLCD	Out
24	LCDVEE	In	54	POWERSW	In
25	GND	—	55	GND	—
26	GND	—	56	GND	—
27	ROMCS0	In	57	GND	—
28	IOR	In/Out	58	IOW	In/Out
29	DR0/1 F4	Out	59	WGATE F18	Out
30	HDLED	Out	60	SMRAMCS	Out


Top View of Main PCB (Lower)



(For Main PCB (Upper))

CN10 PCB Connector (80-pin)

Pin No.	Signal Name/ Description	Direction	Pin No.	Signal Name/ Description	Direction
1	SA1	In/Out	41	SA0	In/Out
2	SA3	In/Out	42	SA2	In/Out
3	SA5	In/Out	43	SA4	In/Out
4	SA7	In/Out	44	SA6	In/Out
5	SA9	In/Out	45	SA8	In/Out
6	SA11	In/Out	46	SA10	In/Out
7	SA13	In/Out	47	SA12	In/Out
8	SA15	In/Out	48	SA14	In/Out
9	SA17	In/Out	49	SA16	In/Out
10	SA19	In/Out	50	SA18	In/Out
11	GND	—	51	GND	—
12	SD0	In/Out	52	SD1	In/Out
13	SD2	In/Out	53	SD3	In/Out
14	SD4	In/Out	54	SD5	In/Out
15	SD6	In/Out	55	SD7	In/Out
16	SD8	In/Out	56	SD9	In/Out
17	SD10	In/Out	57	SD11	In/Out
18	SD12	In/Out	58	SD13	In/Out
19	SD14	In/Out	59	SD15	In/Out
20	GND	—	60	GND	—
21	REFRESH	Out	61	SYSCLK	In
22	IOCHRDY	In/Out	62	PDCLK	In/Out
23	VGACS	Out	63	IOCS16	In/Out
24	PWRGOOD	Out	64	CHGLED	Out
25	OWS	Out	65	REFREQ	Out
26	STPCLK	Out	66	SMI	Out
27	HALT	In	67	INTA	In
28	A20GATE	Out	68	DMA8/16	Out
29	LA17	In/Out	69	HLDA	In
30	LA19	In/Out	70	LA18	In/Out
31	LA21	In/Out	71	LA20	In/Out
32	LA23	In/Out	72	LA22	In/Out
33	GND	—	73	GND	—
34	HRQ	Out	74	INTR	Out
35	NMI	Out	75	CPURESET	Out
36	MASTER	Out	76	ERROR	In
37	BALE	In	77	SUSSTAZ	Out
38	LCDPWR	In	78	BATLED	Out
39	FLVAR	Out	79	CONVAR	Out
40	VDD	Out	80	VLCD	Out



**CN11 VGA Monitor Port (15-pin)**

Pin No.	Signal Name/Description	Direction
1	RED	Out
2	GREEN	Out
3	BLUE	Out
4	MS2	—
5	DGND	—
6	RGND	—
7	GGND	—
8	BGND	—
9	NC	—
10	DGND	—
11	MS0	—
12	MS1	—
13	HSD	Out
14	VSD	Out
15	NC	—

**CN12 DC-IN (2-pin)**

Pin No.	Signal Name/Description	Direction
1	+23V	In
2	GND	—

**CN13 BATTERY PACK Connector (4-pin)**

Pin No.	Signal Name/Description	Direction
1	VSENS	In
2	TSENS	In
3	GND	—
4	ISENS	In

## 2. Diagnostic Test

### 2.1 Outline of Diagnostic Test

This diagnostic test program is prepared for the purpose of testing and troubleshooting hardware functions of the computer.

This program is loaded from the disk drive and operates under the management of MS-DOS.

Some tests (i.e. MAIN BOARD, RAM, and FLOPPY DISK DRIVE) can be done in ROM-based test program.

#### Diagnostic Menu (Main Menu)

This is the menu for the testing procedures (the menu is a list of choices available to you). This menu lists the various components of your computer system that are available for testing.

Each item on the menu is described below. The menu you obtain may differ slightly depending on the devices installed in your computer system.

Note: Refer to items of step 3) Preparation of 2.4 Diagnostic Test Procedure on page 2-18 before starting the Diagnostic Test.

If you choose:

#### (1) TEST ALL DEVICES

Each device is checked in sequence. Notice that this item is automatically programmed as the default choice. Press the [Enter] key to begin the testing.

Press the [Ctrl] and [Break] keys to stop the testing and return to the DIAGNOSTIC MENU.

#### (2) TEST AUTOMATICALLY

All the devices will be tested without further input from you. This testing will continue to operate until you press the [Ctrl] and [Break] keys to stop the cycle.

#### (3) CHANGE MENU

Allows you to add or delete items from the testing menu for the TEST ALL DEVICES or TEST AUTOMATICALLY selection.

#### (4) EXIT

If you decide that you do not wish to proceed with the diagnostic testing, select this item to reboot.

#### (5) MAIN BOARD

Tests the Main Board

#### (6) xxx KB RANDOM ACCESS MEMORY

Tests the base memory and extended memory. (The number of KB or K-bytes will change depending on the configuration of your system.)

#### (7) KEYBOARD

Tests the keyboard.

#### (8) TRACK BALL

Tests the track ball.

#### (9) BATTERY

Tests the battery pack.

#### (10) 1 FLOPPY DISK DRIVE(S)

Tests the floppy disk drive connected to the system.

#### (11) 1 HARD DISK DRIVE(S)

Tests the hard disk drive connected to the system.

#### (12) VIDEO

Tests the color/monochrome mode display of LCD.

If you have an analog monitor, you can test display.

#### (13) 1 PARALLEL PORT(S)

Tests the parallel port and external printer connected to the system.

#### (14) 2 SERIAL PORT(S)

Tests the RS-232C serial port connected to the system.

## Making a Selection

There are a number of items shown in the menu that you can choose from.

To select an item from the menu, move the reverse display (the item displayed in reverse video) to the desired item with the <Up-Arrow> key (upward) or <Down-Arrow> key (downward).

At the same time, the number for SELECT MENU at the bottom of the menu will automatically change to match the item.

(You can type the number of the desired option instead of using <Up-Arrow> or <Down-Arrow> key.)

Then press the <Enter> key.

In most cases, you will test the entire system using the first item on the menu (1. TEST ALL DEVICES).

The testing example in this manual will cover the entire testing procedure as contained in the first item.

To run tests on specific devices, see the sections dealing with that test.

If the correct menu has appeared on your screen, proceed to the next procedure.

## Terminating the Diagnostic Tests


If during the course of testing you wish to stop the procedure, press the [Ctrl] and [Break] keys.

You may need to finish the specific tests being run, (complete the keyboard testing sequence for example) but at the conclusion of the current test, you will return to the menu.

You must press the [Ctrl] and [Break] keys to stop the automatic testing cycle started with item (2) TEST AUTOMATICALLY.

## 2.2 Diagnostic Description

### 1. Main Board Test



PIC Reading/Writing  
Diagnostic and Interrupt Test

RTC Diagnostic

Gate Array Test

END

Checks and writing of the #0 and #1 IMRs (Interrupt Mask Register) of the PIC (Programmable Interrupt Controller). Verifies whether a PIC #0 interrupt test is carried out properly through a TIMER interrupt test. Verifies whether a PIC #1 interrupt test is carried out properly through an RTC periodical interrupt test.

Confirms that the timer refreshing bit is properly turned on or off. Confirms that the data concerning the time is within the proper range.

Send 0CH data to SKBE.

This command is to perform SKBE test and get result SKBE count 500 msec by internal clock during the test.

And get result from SKBE and check bit 0 and bit 1.

bit 0: 1 GA Write/Read Error

bit 1: 1 ROM Check Sum Error

## 2. RAM Diagnostic

Start

Data Reading /Writing  
Diagnostic

Address Line Diagnostic

Refresh Diagnostic

Data Reading/Writing  
Diagnostic

END

Performs the word reading/writing test using data patterns AAAAH, 5555H, FFFFH and 0000H. This applies to loaded addresses from 01000H to 9FFFFH.

After clearing 64 K bytes, writes FFH only on 8000H and confirms that there is only FFH.

Follows the same procedure as above for the following addresses:

4000H, 2000H, 1000H, 0800H, 0400H, 0200H, 0100H, 0080H, 0040H, 0020H, 0010H, 0008H, 0004H, 0002H, and 0001H.

In order to verify that the refreshing is functioning properly on 1 bank from 10000H, confirms that the data is perfectly stored after waiting for more than 2 seconds.

Checks reading and writing of the 1408KB RAM (on MAIN LOGIC BOARD) and optional RAM cards under the Extended RAM mode.

### 3. Keyboard Diagnostic

Start

Keyboard Codes Diagnostic

Press any key to recall a scanning code, which is converted to an ASCII code. Confirms that the ASCII code corresponds to the denotation shown on the top of the pressed key.

The following international character sets are available; USA, Germany, France, Italy, U.K., Spain, Sweden, Swiss (Gr).

Keyboard Controller Diagnostic

Confirms that commands for the keyboard controller are being accepted properly; that is, interrupt will take place after those commands are accepted and proper codes are returned.

END

### 4. Floppy Disk Diagnostic

Start

FDC (Floppy Disk Controller) Diagnostic

Resets the FDC (initialize the reset bit of the digital output register in the FDC) and the FDC will be ready after a fixed period of time. Resets the FDC and FDD and confirms both of them have been properly initialized (INT 13H, AH=0)

FDD (Floppy Disk Drive) Diagnostic

Resets the FDC and FDD. Performs seeking to the track of the largest number and confirms that seeking has been carried out properly. Then performs seeking to track No. 0 and confirms that seeking has been carried out properly.

FDD Format Diagnostic

Sets the parameters according to the FDD and the media (INT 13H, AH=18H). Repeats the following procedure on each track from No. 0 to the largest No.; executes formatting of each track and confirms that it has been carried out properly.

FDD Reading/Writing Diagnostic

Sets the parameters according to the FDD and the media. Repeats the following procedure on each track from No. 0 to the largest No.; Writes (INT 13H, AH=03H) and confirms that writing has been carried out properly. READ (INT 13H, AH=02H) and confirms that reading has been carried properly.

FDD Sequential Seek Diagnostic

Sets the parameters according to the FDD and the media. The following procedure on each track from No. 0 to the largest No.; Reads and verifies (INT 13H, AH=04H) and confirms that seeking has been carried out properly. Repeats the following procedure on each track from No. 0 to the largest No.; Reads and compares the result with the data of the reading/writing test to confirm that both values are equal.

FDD Random Seek Diagnostic

END

Sets the parameters according to the FDD and the media. Selects all tracks at random among tracks from No. 0 to the largest No. and repeats the following procedure on each track; Reads and verifies (INT 13H, AH=04H) and confirms that seeking has been carried out properly.  
Selects all tracks at random among tracks from No. 0 to the largest No. and repeats the following procedure; Reads and compares the result with the data of the reading/writing test to confirm that both values are equal.

## 5. Hard Disk Diagnostic

Start

HDC (Hard Disk Controller) Diagnostic

Resets the HDC and HDD, and confirms that it has been carried out properly (INT 13H, AH=0H).  
Performs the HDC self-test to confirm that the HDC is functioning properly (INT 13H, AH=14H).

HDD (Hard Disk Drive) Diagnostic

Confirms that the HDD is READY (INT 13H, AH=01H).  
Recalibrates the HDD and confirms that the calibration has been carried out properly (INT 13H, AH=11H).  
Performs seeking procedure up to the maximum No. cylinder in the HDD and confirms that the seeking has been carried out properly.  
At the same time, displays the count value until reception of the seeking procedure finish signal.

HDD Reading/Writing (with ECC) Diagnostic

Performs the writing test on the cylinder of the largest No. in the HDD and then with the head of the largest No.  
Formats one track of the HDD and confirms that the formatting has been carried out properly. Writes one track with ECC (Error Correcting Code) and confirms that writing can be carried out properly.  
Reads one track with ECC and confirms that reading can be carried out properly. Confirms that the written data is equal to the read data.

HDD Reading/Writing (with ECC) Diagnostic (Using Error Data)

Creates the error data (5 bits-reversed data correctable by ECC).  
Writes one sector with ECC and confirms that writing has been carried out properly. Reads one sector with ECC and confirms that reading has been carried out properly (confirms that the generated errors can be corrected by the ECC before reading).

HDD Reading/Writing Diagnostic

Writes one sector and confirms that writing has been carried out properly.  
Reads one sector and confirms that reading has been carried out properly.

Sequential Seek Diagnostic


While seeking cylinders from No. 0 to the largest No., performs the following test; Reads and verifies the heads from No. 0 to the largest No. and confirms that the seeking has been carried out properly.

Random Seek Diagnostic


Selects some cylinders at random and performs the following test on each cylinder; Reads and verifies on heads from No. 0 to the largest No. and confirms that the seeking has been carried out properly.

END

## 6. Video Diagnostic




## 7. Parallel Port Diagnostic



Confirms that the printer I/O ports have been set. Resets printer and confirms that the initialization has been carried out properly. Executes printing and confirms that it has been carried out properly.

## 8. Serial Port Test



Performs the reading and writing test for the interrupt register and divider register and checks whether the setting is carried out properly.

Performs the internal loop-back test in the following procedures;

- Sets the transferring rate (9600 bps)
- Sets the transferring system (8 bit, even parity, parity check and 2 stop bit).
- Sets the loop-back mode.
- Transmits the data.
- Ready to receive the data?
- No error generated in the received data?
- Is the received data equal to the transmitted data?

Loops the data that is to be transmitted 256 times and then checks it.


Performs the external loop-back test in the following procedures;

- Sets the mode controlling register.  
RTS ON (Request To Send)  
DTR ON (Data Terminal Ready)
- Confirms that following responses will be returned.  
RTS outputs ON signal  $\Rightarrow$  RLSD (CD) and CTS receive ON signal  
DTR outputs ON signal  $\Rightarrow$  DSR and RI receive ON signal

Rewrites the INT CH vector and confirms that interrupts from the next serial port will be adequately generated.


1. Checks that no line status interrupts, frame error, parity error nor overrun error have occurred.
2. Checks whether it is ready for receiving data interrupts and confirms that the transmitted data is equal to the received one.
3. Checks the transmitting interrupts register and transmitting register are empty.

9. **Track Ball Test**



Get the track ball status and outputs this status to display.

10. **Battery Test**



Send 0C1H data to SKBE to get 1 byte result data from SKBE and check the result data.

## 2.3 Error messages

This section describes diagnostic messages:

Power-On Self Test messages and User Diagnostic messages.

### Power-On Self Test Messages

Power-On Self Test and boot messages are displayed during the power-on process. There are two types of messages:

- Error messages that indicate a failure with either the hardware, software or firmware.
- Informational messages that provide important information about the power-on and boot processes, such as memory status.

However, sometimes the above messages cannot be reported on the screen.

In such cases, Beep codes are used to identify an error in the Power-On Self Test that occurs when the screen is not available.

Refer to the following lists of error messages, informational messages, and Beep codes.

### Resume Function Error Messages in the Power-On Self Test

BIOS should display an error message when resuming has failed in the following three ways.

- Resume failure  
When BIOS detects resuming has failed due to an error at failing into suspended. Example: BIOS didn't get the correct IRQ5.
- Resume memory backup failure  
When BIOS detects resuming has failed due to an error at resuming. Example: DRAM checksum is bad.

### Error Messages in the Power-On Self Test

Diskette Seek to track 0 failed  
Drive A has either failed or is missing.

Diskette drive reset failed  
FDC (Floppy Disk Controller) has failed.

Diskette read failure...strike F1 to retry boot  
Disk is either not formatted or defective.

Gate A20 failure  
Protected mode cannot be enabled.

Hard disk controller failure  
HDC (Hard Disk Controller) has failed.

Hard disk failure  
Hard disk has failed.

Hard disk read failure...strike F1 to retry boot  
Hard disk is defective.

Invalid configuration information...please run SETUP program  
User should run SETUP480 utility first.

Keyboard clock line failure  
Keyboard is defective.

Keyboard data line failure  
Keyboard is defective.

Keyboard controller failure  
Keyboard controller firmware has failed.

Keyboard stuck key failure  
A key(s) is(are) jammed.

Memory address line failure at xxxxxxxx, read xxxxxxxx expecting xxxxxxxx  
Circuitry associated with the memory chips has failed.

Memory data line failure at xxxxxxxx, read xxxxxxxx  
One of the memory chips or associated circuitry has failed.

Memory high address line failure at xxxxxxxx-xxxxxxx  
Circuitry associated with the memory chips has failed.

Memory odd/even failure at xxxxxxxx, read xxxxxxxx expecting xxxxxxxx  
Circuitry associated with the memory chips has failed.

Memory write/read failure at xxxxxxxx, read xxxxxxxx expecting xxxxxxxx  
One of the memory chips or associated circuitry has failed.

No boot device available...strike F1 to retry boot  
Either floppy disk drive A, hard disk, or floppy disk itself is defective.

No boot selector on hard disk...strike F1 to retry boot  
Drive C is not formatted.

No time tick interrupt  
Timer chip has failed.

Not a boot diskette...strike F1 to retry boot  
Floppy disk in drive A is not formatted as a bootable disk.

Shutdown failure  
Keyboard controller or its associated logic has failed.

Time-of-day clock stopped  
CMOS real-time clock chips have failed.

Time chip counter 2 failed  
Timer chip counter has failed.

Timer or Interrupt Controller bad  
Either timer chip or interrupt controller is defective.

Unexpected interrupt in protected mode  
Non-maskable interrupt (NMI) port can't be disabled.

## Informational Messages in the Power-On Self Test

MEMORY SIZE=xxxx KB

This amount of memory has been tested successfully.

Decreasing available memory

Memory chips are failing.

Followed by any memory error messages.

Memory tests terminated by keystroke

Memory tests stopped by your hitting the <spacebar> while the memory tests were running.

Strike the F1 key to continue

An error was found during Power-On Self Test. Attempt to boot the system hitting the F1 key.

## Beep Codes

The beep codes that aren't followed by any error messages and are written to Port 80H for fatal system board errors, are listed.

Note: Beep codes on the left column in the list below indicate the pattern of beep code bursts (e.g., 1-1-3 is one beep, followed by another beep, followed by a burst of three beeps.)

none CPU register test in progress  
1-1-3 CMOS write/read failure  
1-1-4 ROM BIOS checksum failure  
1-2-1 Programmable interval Timer failure  
1-2-2 DMA initialization failure  
1-2-3 DMA page register write/read failure  
1-3-1 RAM refresh verification failure  
none 1st 64K RAM test in progress  
1-3-3 1st 64K RAM chip or data line failure multi-bit  
1-3-4 1st 64K RAM odd/even logic failure  
1-4-1 Address line failure 1st 64K RAM  
1-4-2 Parity failure 1st 64K RAM  
2-1-1 Bit 0 1st 64K RAM failure  
2-1-2 Bit 1 1st 64K RAM failure  
2-1-3 Bit 2 1st 64K RAM failure  
2-1-4 Bit 3 1st 64K RAM failure  
2-2-1 Bit 4 1st 64K RAM failure  
2-2-2 Bit 5 1st 64K RAM failure  
2-2-3 Bit 6 1st 64K RAM failure  
2-2-4 Bit 7 1st 64K RAM failure  
2-3-1 Bit 8 1st 64K RAM failure  
2-3-2 Bit 9 1st 64K RAM failure  
2-3-3 Bit A 1st 64K RAM failure  
2-3-4 Bit B 1st 64K RAM failure  
2-4-1 Bit C 1st 64K RAM failure  
2-4-2 Bit D 1st 64K RAM failure  
2-4-3 Bit E 1st 64K RAM failure

2-4-4 Bit F 1st 64K RAM failure  
3-1-1 Slave DMA register failure  
3-1-2 Master DMA register failure  
3-1-3 Master interrupt mask register failure  
3-1-4 Slave interrupt mask register failure  
none Interrupt vector loading in progress  
3-2-4 Keyboard controller test failure  
none CMOS power failure and checksum calculation in progress  
none CMOS config inform validation in progress  
3-3-4 Screen memory test failure  
3-4-1 Screen initialization failure  
3-4-2 Screen retrace test failure  
none Search for video ROM in progress  
none Screen believed operable  
none Screen believed running with video ROM  
none Monochrome monitor believed operable  
none Color monitor (40 column) believed operable  
none Color monitor (80 column) believed operable  
Note: No beep code is sounded if a test is aborted while in progress.

## User Diagnostic Messages

Various messages or error messages that may appear in User Diagnostics are below.

You may find also a code number in the message. By looking up the code number in the code table, the detailed status of a device can be determined.

Example: In a message of the printer port test like:  
PPA Time out error occurred with parallel printer  
BIOS status: n1n2  
Character: n3n4

A hexadecimal nibble in the message consists of the following 4 bits:

n=D3 D2 D1 D0

For example, if n1=5, a hexadecimal 5 is expressed as 0101 in binary codes, then D3=0, D2=1, D1=0, D0=1

Also,

n1=D (1101) then D3=1, D2=1, D1=0, D0=1

Look up the number in the code table and clarify the problem.

## Main Board Test

- (1) System ROM checksum test  
ROM System ROM checksum error  
Checksum: xx
- (2) CMOS RAM shutdown byte r/w test  
CRAM Shutdown byte test failed.  
Write data: xxxx Read data: xxxx
- (3) Programmable interrupt timer test  
PIT Timer #2 counter r/w failed.  
Write data: xx Read data: xx  
PIT Timer count failed.  
High count value expected: 00 current data: xx
- (4) Page register r/w test  
PREG Page register r/w test failed. (byte) xx Read data: xx  
PREG Page register r/w test failed. (word) xx Read data: xx
- (5) DMA controller register r/w test  
DMAC DMA controller register r/w test failed.  
I/O address: xxxx Write data: xxxx Read data: xxxx
- (6) Keyboard controller test  
KBCTRL Keyboard controller input buffer full.  
KBCTRL Keyboard line always low. (clock)  
KBCTRL Keyboard line always high. (clock)  
KBCTRL Keyboard line always low. (data)  
KBCTRL Keyboard line always high. (data)  
KBCTRL Keyboard controller output buffer empty.  
KBCTRL Keyboard controller self test failed.  
Return code: xx
- (7) Programmable interrupt controller test  
PIC PIC #0 interrupt mask register failed.  
Write data: xx Read data: xx  
PIC PIC #1 interrupt mask register failed.  
Write data: xx Read data: xx  
PIC PIC #0 handling error  
ISR status: xx  
PIC PIC #1 handling error  
ISR status: xx  
PIC PIC #0 no interrupt occurred.  
PIC PIC #1 no interrupt occurred.
- (8) Realtime clock test  
RTC Realtime clock UIP bit always ON.  
RTC Realtime clock UIP bit always OFF.  
RTC Realtime clock data out of range.  
(Second data: ss)  
(Minute data: mm)  
(Hour data: hh)  
(Date data: dd)  
(Month data: mm)  
(Year data: yyyy)
- (9) GATE Array test  
Gate Array write/read Test Error.  
SKBE ROM check sum Error.

## RAM Test

- (1) DRAM read/write test  
 DRAM R/W test failed.  
 Address: xxxxxx Write Data: xxxx Read Data: xxxx
- (2) DRAM refresh test  
 DRAM Refresh test failed  
 Address: xxxxxx Read Data: xx
- (3) DRAM address test  
 DRAM Address test failed  
 Address: xxxxxx Read Data: xx
- (4) Extended RAM test  
 EXTENDED RAM Unsuccessful to enter Protect Mode.  
 EXTENDED RAM R/W test failed.  
 Address: xxxxxx Write Data: xxxx Read Data: xxxx  
 EXTENDED RAM Address Line test failed.  
 Address Line: xxxxxx, xxxxxx  
 EXTENDED RAM Refresh test failed.

## Keyboard Test

- (1) Keyboard reset test  
 KEY Keyboard failed.
- (2) Keyboard data test  
 KEY Key has been hit or broken.  
 SCAN CODE: xx

## Floppy Disk Drive Test

FDC FDC failed.  
 Master status: n1n2  
 Floppy Disk Controller (FDC) master status has failed.  
 Data bus or FDC chip has failed.  
 n1n2 is FDC master status listed below.

FDC master status

Nibble	Bit	Meaning
n1	D3	1: FDC data register is ready to receive and transmit data
	D2	1: Transmit data from FDC to processor
	D1	1: Transmit in non-DMA mode
	D0	1: FDC is busy
n2	D3	_____
	D2	_____
	D1	1: Seek in drive B
	D0	1: Seek in drive A

FDC Init. failed BIOS status: xx  
 Floppy Disk Controller (FDC) initialization has failed.  
 Data bus or FDC chips have failed.  
 xx is BIOS disk error status below.

**BIOS disk error status**

Status	Meaning
80	Time out
40	Seek out
20	FDC failed
10	CRC error
09	DMA boundary
08	DMA overrun
03	Media change line active
06	No record
04	Write protected
02	No address mark
01	Invalid command

FDC                    Seek failed (max track)  
                           Seek has failed.  
                           Floppy Disk Controller (FDC) cable or FDC chip has failed.

FDC                    Seek failed (0 track)  
                           Seek has failed.  
                           Floppy Disk Controller (FDC) cable or FDC chip has failed.

When an error occurs during format, verify, write and read tests for FDD, it is displayed with the following format and combination of command and error names:

**(Format of Error Message)**

[Command Name] failed: [Error Name] Cylinder=xx    Head=xx    Sector=xx
---

Command Name: Read	Error Name:	HDC not found (FFH)
Write		Bad err register (E0H)
Verify		Write fault (CCH)
Format		Undefined error (BBH)
Read long		Drive not ready (AAH)
Write long		Timeout (80H)
Command		Seek error (40H)
		FDC or HDC error (20H)
		Data corrected (11H)
		CRC or ECC error (10H)
		Bad track (0BH)
		Bad sector mark (0AH)
		64K boundary (09H)
		DMA overrun (08H)
		Parameter error (07H)
		Reset error (05H)
		Nor record (04H)
		Write protected (03H)
		No address mark (02H)
		Invalid command (01H)

When there is a difference between write data and read data, the following error message is displayed:

Compare error Cylinder=xx    Head=xx    Sector=xx

## Serial Port Test

- (1) Register test  
 RS232 Serial port failed.  
 Interrupt ID Write: xx Read: xx  
 RS232 Serial port failed.  
 Divisor Write: xxxx Read: xxxx
- (2) internal loopback  
 RS232 Serial port data loopback failed.  
 Line & Modem status: n1n2, n3n4  
 n1n2n3n4: Refer to the tables of loopback line status and loopback modem status below.  
 RS232 Serial port data loopback failed.  
 Xmit: xx Recv: xx  
 RS232 Serial port signal loopback failed.  
 Modem status: n3n4 Expected: n3' n4'  
 n3n4: result by test. Refer to the table of modem status below.  
 n3' n4' : expected status
- (3) External loopback  
 RS232 Serial port signal real loopback test failed.  
 Modem status: n3n4 Expected: n3' n4'  
 n3n4: Refer to the table of modem status below.  
 RS232 Serial port data real loopback test failed.  
 Line status: n1n2  
 n1n2: Refer to the table of line status below.  
 RS232 Serial port data real loopback test failed.  
 Xmit: xx Recv: xx  
 RS232 Data real loopback transmit failed.  
 Line status: n1n2  
 n1n2: Refer to the table of line status below.  
 RS232 Data real loopback interrupt request failed.  
 Line status: n1n2  
 n1n2: Refer to the table of line status below.  
 RS232 Data real loopback receive failed.  
 Line status: n1n2  
 n1n2: Refer to the table of line status below.

Loopback line status

Nibble	Bit	Meaning
n1	D3	1: Timing out
	D2	1: Transmit shift register
	D1	1: Transmit-holding register is empty
	D0	1: Break detect
n2	D3	1: Framing error
	D2	1: Parity error
	D1	1: Overrun error
	D0	1: Data ready

Loopback modem status

Nibble	Bit	Meaning
n3	D3	1: Carrier detect (CD)
	D2	1: Ring indicator (RING)
	D1	1: Data set ready (DSR)
	D0	1: Clear to send (CTS)
n4	D3	_____
	D2	_____
	D1	_____
	D0	_____

**Printer Port Test**

PPA

Time out error occurred with parallel printer

BIOS status: n1n2 Character: xx

PPA

I/O error occurred with parallel printer.

BIOS status: n1n2 Character: xx

PPA

Paper end occurred with parallel printer

BIOS status: n1n2

Character: xx

n1n2 is a printer BIOS error status listed below.

xx is the character sent to the printer.

Printer BIOS error status

Nibble	Bit	Meaning
n1	D3	0: Busy
	D2	1: Acknowledge
	D1	1: Paper end
	D0	1: Printer is selected
n2	D3	1: I/O error
	D0	1: Time out

## Hard Disk Drive Test

- **HDC RESET TEST**  
HDC reset failed.
- **HDC DIAGNOSTICS TEST**  
HDC internal diagnostic failed.
- **HDD SET PARAMETER TEST**  
HDD set drive parameter failed.  
BIOS status: xx    HDC status: xx    HDC error status: xx
- **HDD DRIVE READY TEST**  
HDD drive not ready.  
BIOS status: xx    HDC status: xx    HDC error status: xx
- **HDD RECALIBRATE TEST**  
HDD recalibrate failed.  
BIOS status: xx    HDC status: xx    HDC error status: xx
- **HDD SEEK TEST**  
HDD seek failed.  
BIOS status: xx    HDC status: xx    HDC error status: xx
- **HDD SEEK TIME TEST**  
HDD seek does not complete within some period.  
BIOS status: xx    HDC status: xx    HDC error status: xx

Get parameter error — Can not execute test program!

BIOS status: xx    HDC status: xx    HDC error status: xx

Note: See the following tables for the status represented by xx, n1n2 and n3n4.

BIOS error status

Status	Meaning
FF	Sense status failed
E0	Bad error register
CC	Write fault
BB	Undefined error
AA	Drive not ready
80	Time out
40	Seek error
20	Controller failed
11	ECC corrected data error
0B	Bad track
09	DMA boundary
08	DMA overrun
07	Drive parameter error
05	Reset failed
04	No record
03	Write protected
02	No address mark
01	Invalid command

### HDC status

Nibble	Bit	Meaning
n1	D3	1: HDC is busy
	D2	1: HD is ready
	D1	1: Write fault signal from HD
	D0	1: Seek is completed
n2	D3	1: HDC requests to transmit data
	D2	1: ECC corrected data
	D1	1: Index pulse signal
	D0	1: Error found in executed instructions

### HDC error status

Nibble	Bit	Meaning
n3	D3	1: Back block
	D2	1: Non-correctable ECC error
	D1	1: _____
	D0	1: Selector not found
n4	D3	1: _____
	D2	1: HD not ready
	D1	1: No track 00 signal
	D0	1: No address mark

When an error occurs during format, write long, read long, write and read tests for HDD, it is displayed with the following format and combination of command and error names:

#### (Format of Error Message)

[Command Name] failed: [Error Name] Cylinder=xx    Head=xx    Sector=xx
---

Command Name: Please refer to the FDD section on page 2-13.

Error Name: Please refer to the FDD section on page 2-13.

#### Battery Test

Battery abnormal high voltage

Battery charging current overflow

Battery temperature > 100°C

Battery temperature < -22°C and voltage > 3.3V

Battery Status error


## 2.4 Diagnostic Test Procedure

### 1) Equipment

Required

(1) Test Laptop Computer .....	1 unit
(2) AC Adapter .....	1 pc.
(3) External Printer .....	1 unit
(4) Loopback Plug (Serial Port Test for RS232C) [P/N: DFVV95C0067] .....	1 pc.
(5) Loopback Cable (Serial Port Test for MODEM) [P/N: DFVV95C0068] .....	1 pc.
(6) Installation Disk 1 .....	1 pc.

### 2) Equipment Connection




### 3) Preparation

- (1) Be sure connections are made as shown above.
- (2) Run the Setup383/Set1660 program and set all parameters to the factory settings to ensure that menu items are properly displayed.
- (3) Run the Power383/Powr1660 program and enable the serial ports.
- (4) Temporarily rename the CONFIG.SYS file and reboot the computer before you start the diagnostics test.
- (5) Remove any optional modem.
- (6) Connect the Loopback Plug and Loopback Cable as shown below.



#### WARNING

Do not connect or disconnect the Loopback Cable into/from the modem socket when the power switch of the computer is ON. Otherwise, the internal fuse could be blown.




## 4) Test Procedure

Step	Test Procedure	Screen Displays:	Criteria	Remarks
1	Insert the Installation Disk 1 into Drive <b>A</b>			
2	Turn on the main power switch of the computer. Then press the reset button of the computer.	Phoenix View/LC (TM) VGA-Compatible BIOS Version xx Ref. x x Copyright (C) 1984 – 1991 Phoenix Technologies Ltd. All Right Reserved Phoenix 80386 ROM BIOS PLUS Version xxxx Copyright (C) 1985 – 1990 Phoenix Technologies Ltd. All right Reserved 640K Base Memory, xxxx K Extended  Strike the F1 key to continue  SuperStor Data Compression Driver Version x.xx,xx-xx-xx Copyright (C) AddStor Inc. 1991, 1992, All rights reserved. SuperStor fixed drive C: mounted as drive D: Drive C and D swapped	<b>Note:</b> Press <b>F1</b> key, when the following message is displayed.  "Resume failure Strike the F1 key to continue"  <b>Note:</b> When "Enter password:" is displayed, press <b>M</b> <b>S J C K L 4</b> (Enter) keys. (Refer to the CAUTION described below.)  <b>CAUTION:</b> The password described above is the master-password which is prepared for servicing purposes only. Thus, do not use it for other than the above purposes and handle it confidentially.  Entering the master-password enables to delete the previous password and disable the system password. However, the master-password will not be registered.	
3		***** * Your hard disk has been already installed. * * Type INSTALL and press Enter to re-installed. * ***** A >		
4	Press <b>D I A G</b> <b>3 8 3</b> or <b>1 6 6 0</b>	A > DIAG383/DIAG1660		
5	Press <b>Enter</b> key.	Do you want printed output? (Y/N) _		
6	Press <b>Y</b> (for "Yes") if you want printed output, otherwise press <b>N</b> key.	DIAGNOSTIC MENU (Ver. x.xx) <b>1. TEST ALL DEVICES ( <input type="checkbox"/> DEVICES )</b> 2. TEST AUTOMATICALLY ( <input checked="" type="checkbox"/> DEVICES ) 3. CHANGE MENU 4. EXIT ■ 5. MAIN BOARD ■ 6. xxxx KB RANDOM ACCESS MEMORY ■ 7. KEYBOARD 8. TRACK BALL 9. BATTERY ■ 10. 1 FLOPPY DISK DRIVE (S) ■ 11. 1 HARD DISK DRIVE (S) ■ 12. VIDEO 13. 1 PARALLEL PORT (S) ■ 14. 2 SERIAL PORT (S)  SELECT MENU : <u>1</u>		
7	Press <b>Enter</b> key.	MAIN BOARD TEST  ----- BASE RAM TEST CURRENT BASE RAM SIZE = 640KB Base RAM = 640KB Check OK  ----- EXTENDED RAM TEST CURRENT EXTENDED RAM SIZE = xxx KB Extended RAM = xxx KB Check OK KEYBOARD RETURN CODE TEST FLOPPY DISK CONTROLLER TEST 1st FLOPPY DISK DRIVE (1.44MFD) TEST  ----- HARD DISK CONTROLLER TEST 1st HDD-DRIVE TEST Count value to get SEEK COMPLETE=0 1st HDD-SEQUENTIAL SEEK TEST Cylinder=xxx 1st HDD-RANDOM SEEK TEST Cylinder=xxx		

Step	Test Procedure	Screen Displays:	Criteria	Remarks																
8		<p style="text-align: center;">40 x 25 , 16 Colors , Text Mode</p> <table border="1" style="width: 100%; text-align: center;"> <tr> <td>VGA Test Pattern 40 x 25 16 Color</td> </tr> <tr> <td>VGA Test Pattern 40 x 25 16 Color</td> </tr> <tr> <td>VGA Test Pattern 40 x 25 16 Color</td> </tr> <tr> <td>VGA Test Pattern 40 x 25 16 Color</td> </tr> </table> <p>Is this correct ? (Y/N) _____</p>	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color		
VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color																	
VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color																	
VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color																	
VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color	VGA Test Pattern 40 x 25 16 Color																	
9	Press <b>Y</b> key.	<p style="text-align: center;">80 x 25 , 16 Colors , Text Mode</p> <table border="1" style="width: 100%; text-align: center;"> <tr> <td>Black VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Dark Gray VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>White VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Int White VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> </tr> <tr> <td>Red VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Light Red VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Magenta VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Light Magenta VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> </tr> <tr> <td>Green VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Light Green VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Brown VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Yellow VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> </tr> <tr> <td>Blue VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Light Blue VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Cyan VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> <td>Light Cyan VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors</td> </tr> </table> <p>Is this correct ? (Y/N) _____</p>	Black VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Dark Gray VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	White VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Int White VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Red VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Red VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Magenta VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Magenta VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Green VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Green VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Brown VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Yellow VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Blue VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Blue VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Cyan VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Cyan VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors		
Black VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Dark Gray VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	White VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Int White VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors																	
Red VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Red VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Magenta VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Magenta VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors																	
Green VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Green VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Brown VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Yellow VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors																	
Blue VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Blue VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Cyan VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors	Light Cyan VGA Test Pattern 80x25, 16 Colors VGA Test Pattern 80x25, 16 Colors																	
10	Press <b>Y</b> key.																			
11	Press <b>Y</b> key.																			






Step	Test Procedure	Screen Displays:	Criteria	Criteria																						
22	Press <b>Y</b> key.	<p>80 x 25 , 2 Colors , Text Mode</p> <table border="1"> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Normal</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Reverse</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Intensity</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Underline</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Blink</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Intensity &amp; Underline</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Underline &amp; Blink</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Intensity &amp; Blink</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Reverse &amp; Intensity</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Reverse &amp; Blink</td> </tr> <tr> <td>VGA Test Pattern / 80x25, 2 Colors</td> <td>Reverse &amp; Intensity &amp; Blink</td> </tr> </table> <p>Is this correct ? (Y/N) _____</p>	VGA Test Pattern / 80x25, 2 Colors	Normal	VGA Test Pattern / 80x25, 2 Colors	Reverse	VGA Test Pattern / 80x25, 2 Colors	Intensity	VGA Test Pattern / 80x25, 2 Colors	Underline	VGA Test Pattern / 80x25, 2 Colors	Blink	VGA Test Pattern / 80x25, 2 Colors	Intensity & Underline	VGA Test Pattern / 80x25, 2 Colors	Underline & Blink	VGA Test Pattern / 80x25, 2 Colors	Intensity & Blink	VGA Test Pattern / 80x25, 2 Colors	Reverse & Intensity	VGA Test Pattern / 80x25, 2 Colors	Reverse & Blink	VGA Test Pattern / 80x25, 2 Colors	Reverse & Intensity & Blink		
VGA Test Pattern / 80x25, 2 Colors	Normal																									
VGA Test Pattern / 80x25, 2 Colors	Reverse																									
VGA Test Pattern / 80x25, 2 Colors	Intensity																									
VGA Test Pattern / 80x25, 2 Colors	Underline																									
VGA Test Pattern / 80x25, 2 Colors	Blink																									
VGA Test Pattern / 80x25, 2 Colors	Intensity & Underline																									
VGA Test Pattern / 80x25, 2 Colors	Underline & Blink																									
VGA Test Pattern / 80x25, 2 Colors	Intensity & Blink																									
VGA Test Pattern / 80x25, 2 Colors	Reverse & Intensity																									
VGA Test Pattern / 80x25, 2 Colors	Reverse & Blink																									
VGA Test Pattern / 80x25, 2 Colors	Reverse & Intensity & Blink																									
23	Press <b>Y</b> key.																									
24	Press <b>Y</b> key.	<p>1st serial port test (I/O address 3F8H)</p> <hr/> <p>1st serial port test (I/O address 3F8H)  2nd serial port test (I/O address 2F8H)  2nd serial port test (I/O address 2F8H)</p> <p>Test done!! Hit any key when ready_</p>																								
25	Press any key.	<p>DIAGNOSTIC MENU (Ver. x.xx)</p> <ul style="list-style-type: none"> <li>1. TEST ALL DEVICES (■ DEVICES)</li> <li>2. TEST AUTOMATICALLY (■ DEVICES)</li> <li>3. CHANGE MENU</li> <li>4. EXIT</li> <li>■ 5. MAIN BOARD</li> <li>■ 6. xxxx KB RANDOM ACCESS MEMORY</li> <li>■ 7. KEYBOARD</li> <li>8. TRACK BALL</li> <li>9. BATTERY</li> <li>■ 10. 1 FLOPPY DISK DRIVE (S)</li> <li>■ 11. 1 HARD DISK DRIVE (S)</li> <li>■ 12. VIDEO</li> <li>13. 1 PARALLEL PORT (S)</li> <li>■ 14. 2 SERIAL PORT (S)</li> </ul> <p>SELECT MENU : <u>1</u></p>																								
26	Press <b>7</b> keys and <b>Enter</b> kys.	<p>KEYBOARD</p> <ul style="list-style-type: none"> <li>1. TEST ALL DEVICES (■ DEVICES)</li> <li>2. TEST AUTOMATICALLY (■ DEVICES)</li> <li>3. CHANGE MENU</li> <li>4. EXIT</li> <li>5. PRESS KEY TEST</li> <li>■ 6. SCAN CODE RETURN TEST</li> </ul> <p>SELECT MENU: <u>1</u></p>																								



Step	Test Procedure	Screen Displays:	Criteria	Remarks
32	Press <b>4</b> and <b>Enter</b> keys.	DIAGNOSTIC MENU (Ver. x.xx) 1. TEST ALL DEVICES (■ DEVICES) 2. TEST AUTOMATICALLY (■ DEVICES) 3. CHANGE MENU 4. EXIT ■ 5. MAIN BOARD ■ 6. xxxx KB RANDOM ACCESS MEMORY ■ <b>7. KEYBOARD</b> 8. TRACK BALL 9. BATTERY ■ 10. 1 FLOPPY DISK DRIVE (S) ■ 11. 1 HARD DISK DRIVE (S) ■ 12. VIDEO 13. 1 PARALLEL PORT (S) ■ 14. 2 SERIAL PORT (S)  SELECT MENU : <u>7</u>		
33	Press <b>1</b> <b>3</b> keys and <b>Enter</b> kys.	1st Parallel port test (I/O address 378H) Connect printer Hit any key when ready_		
34	Press any key.	Test done!! Hit any key when ready_  Printing Sample  <pre> 1st Parallel port test (I/O address 378H) !*"546"()*+,-./0123456789;:&lt;=&gt;?@ABCDEFGHIJKLMNQRSTUWXYZ{\} _`"~'abcdefghijklmnopqrstuvwxyz !"#\$%&amp;'()*+,-./0123456789;:&lt;=&gt;?@ABCDEFGHIJKLMNQRSTUWXYZ{ }_`"~'abcdefghijklmnopqrstuvwxyz </pre>		
35	Press any key.	DIAGNOSTIC MENU (Ver. x.xx) 1. TEST ALL DEVICES (■ DEVICES) 2. TEST AUTOMATICALLY (■ DEVICES) 3. CHANGE MENU 4. EXIT ■ 5. MAIN BOARD ■ 6. xxxx KB RANDOM ACCESS MEMORY ■ 7. KEYBOARD 8. TRACK BALL 9. BATTERY ■ 10. 1 FLOPPY DISK DRIVE (S) ■ 11. 1 HARD DISK DRIVE (S) ■ 12. VIDEO ■ <b>13. 1 PARALLEL PORT (S)</b> ■ 14. 2 SERIAL PORT (S)  SELECT MENU : <u>13</u>		
36	Press <b>1</b> <b>4</b> keys and <b>Enter</b> kys.	2 SERIAL PORT (S) ■ <b>1. TEST ALL DEVICES (■ DEVICES)</b> 2. TEST AUTOMATICALLY (■ DEVICES) 3. CHANGE MENU 4. EXIT ■ 5. 1st SERIAL PORT TEST ■ 6. 2nd SERIAL PORT TEST  SELECT MENU: <u>1</u>		


Step	Test Procedure	Screen Displays:	Criteria	Remarks																														
37	Press <b>[5]</b> and <b>[Enter]</b> keys.	<b>1 SERIAL PORT TEST</b> <b>1. TEST ALL DEVICES (1 DEVICES)</b> 2. TEST AUTOMATICALLY (1 DEVICES) 3. CHANGE MENU 4. EXIT 5. RS232C CONTROLLER REGISTER R/W TEST 6. INTERNAL LOOPBACK TEST 7. EXTERNAL LOOPBACK TEST  SELECT MENU: <u>1</u>																																
38	Press <b>[7]</b> and <b>[Enter]</b> keys.	1st serial port test (I/O address 3F8H)  Connect loopback plug  Hit any key when ready_	<b>Note:</b> Check to be sure that loopback plug is connected.																															
39	Press any key.	Test done!! Hit any key when ready_	Loopback plug wiring as shown below. 	<b>Note:</b> Refer to the item (3) of 3) Preparation on page 2-18.																														
40	Press any key.	<b>1 SERIAL PORT TEST</b> 1. TEST ALL DEVICES (1 DEVICES) 2. TEST AUTOMATICALLY (1 DEVICES) 3. CHANGE MENU 4. EXIT 5. RS232C CONTROLLER REGISTER R/W TEST 6. INTERNAL LOOPBACK TEST <b>7. EXTERNAL LOOPBACK TEST</b>  SELECT MENU: <u>Z</u>	<b>Pin Configuration for Serial Port</b> <table border="1"> <thead> <tr> <th>Pin No.</th> <th>Signal Name/Description</th> <th>Direction</th> </tr> </thead> <tbody> <tr><td>1</td><td>CD</td><td>In</td></tr> <tr><td>2</td><td>RXD</td><td>In</td></tr> <tr><td>3</td><td>TXD</td><td>Out</td></tr> <tr><td>4</td><td>DTR</td><td>Out</td></tr> <tr><td>5</td><td>GND</td><td>—</td></tr> <tr><td>6</td><td>DSR</td><td>In</td></tr> <tr><td>7</td><td>RTS</td><td>Out</td></tr> <tr><td>8</td><td>CTS</td><td>In</td></tr> <tr><td>9</td><td>RING</td><td>In</td></tr> </tbody> </table>	Pin No.	Signal Name/Description	Direction	1	CD	In	2	RXD	In	3	TXD	Out	4	DTR	Out	5	GND	—	6	DSR	In	7	RTS	Out	8	CTS	In	9	RING	In	
Pin No.	Signal Name/Description	Direction																																
1	CD	In																																
2	RXD	In																																
3	TXD	Out																																
4	DTR	Out																																
5	GND	—																																
6	DSR	In																																
7	RTS	Out																																
8	CTS	In																																
9	RING	In																																
41	Press <b>[4]</b> and <b>[Enter]</b> keys.	<b>2 SERIAL PORT (S)</b> 1. TEST ALL DEVICES (1 DEVICES) 2. TEST AUTOMATICALLY (1 DEVICES) 3. CHANGE MENU 4. EXIT 5. 1st SERIAL PORT TEST 6. 2nd SERIAL PORT TEST  SELECT MENU: <u>5</u>																																
42	Press <b>[6]</b> and <b>[Enter]</b> keys.	<b>1 SERIAL PORT TEST</b> <b>1. TEST ALL DEVICES (1 DEVICES)</b> 2. TEST AUTOMATICALLY (1 DEVICES) 3. CHANGE MENU 4. EXIT 5. RS232C CONTROLLER REGISTER R/W TEST 6. INTERNAL LOOPBACK TEST 7. EXTERNAL LOOPBACK TEST  SELECT MENU: <u>1</u>	<b>Note:</b> Check to be sure that loopback cable is connected into the MODEM socket. If it is not connected, refer to "WARNING" in 3) Preparation on page 2-18.																															
43	Press <b>[7]</b> and <b>[Enter]</b> keys.	2nd serial port test (I/O address 2F8H)  Confirm loopback plug  Test done!! Hit any key when ready_																																





### 3. Troubleshooting

#### 3.1 Troubleshooting (For Block Exchange)

Note: Before starting the following diagnostic test, refer to items of step "3) Preparation" on page 2-18.







Screen displays messages as shown at right.

```

*****
*Your hard disk has been already installed. *
*Type INSTALL and press Enter to re-install. *
*****
A >_

```

**2) DIAGNOSTIC TEST**

Press **d i a g**  
**3 8 3** or **1 6 6 0**

Note: **[ ]** key denotes **[Enter]** key.

Screen displays messages as shown at right.

```

Do you want printed output? (Y/N)_

```

Press **[Y]** or **[N]** key.

Screen displays messages as shown at right.


```


DIAGNOSTIC MENU (Ver. x.xx)
1. TEST ALL DEVICES ( ■ DEVICES)
2. TEST AUTOMATICALLY ( ■ DEVICES)
3. CHANGE MENU
4. EXIT
■ 5. MAIN BOARD
■ 6. xxxx KB RANDOM ACCESS MEMORY
■ 7. KEYBOARD
■ 8. TRACK BALL
9. BATTERY
■ 10. 1 FLOPPY DISK DRIVE (S)
■ 11. 1 HARD DISK DRIVE (S)
■ 12. VIDEO
■ 13. 1 PARALLEL PORT (S)
■ 14. 2 SERIAL PORT (S)

SELECT MENU : 1


```










9) LCD DISPLAY TEST










**10) KEYBOARD TEST**




**PRESS KEY TEST**

- 1. TEST ALL DEVICES (▣ DEVICES)
- 2. TEST AUTOMATICALLY (▣ DEVICES)
- 3. CHANGE MENU
- 4. EXIT
- 5. U.S.A.
- 6. GERMANY
- 7. FRANCE
- 8. ITALY
- 9. U.K.
- 10. SPAIN
- 11. SWEDEN
- 12. SWISS (Gr)

SELECT MENU: 1

\*Note: Press appropriate number according to the keyboard layout.



**11) 2DD-MEDIA IN 1.44-FDD TEST**

Screen displays messages as shown at right.  
(Refer to Note shown at right.)

Press any key

Is DRIVE FORMATTING TEST OK?

Screen displays: Formatting....

12

C

2DD-MEDIA IN 1.44-FDD TEST

\*\*\*\*\*Warning!!!\*\*\*\*\*

CONTENTS OF DISK WILL BE DESTROYED

\*\*\*\*\*Warning!!!\*\*\*\*\*




Insert scratch 2DD disk into the 1st drive  
Hit any key when ready\_


**Note:**



Remove the "Installation Disk" from the FDD.  
Then insert scratch 2DD disk into the FDD and press any key.

Screen displays ERROR MESSAGE meaning explained in section 2.3.












D







### 3.2 Appearance of Disassembled Block Unit

<b>Main PCB (UPPER)</b> P/N: DFWV48C198Z 		<b>Main PCB (LOWER)</b> P/N: DL3U10510CAA 	
<b>Keyboard Ass'y</b> P/N: ESU54TM404BK 		<b>LCD Unit</b> P/N: DFWV08A025ZA 	
<b>FDD Ass'y</b> P/N: DFJG052YA-M 	<b>HDD</b> P/N: DFJH003ZA-C 	<b>FL Inverter PCB</b> P/N: DFWV48C194Z 	
<b>Track Ball Ass'y</b> P/N: EMU-15901 	<b>Contrast Control PCB</b> P/N: DL3U10484AAA 	<b>Power/Battery LED PCB</b> P/N: DL3U20510CAA 	<b>LED/Switch PCB</b> P/N: DL3U40510CAA 


## 4. Disassembly/Reassembly

**Note:** Before disassembling, be sure to preform the following procedures first.

1. Turn the power switch off.
2. Disconnect the AC adapter and remove the battery pack described below.
3. Remove the floppy disk if it is inserted in the floppy disk drive.
4. Remove the optional RAM board and MODEM card if they are installed (Refer to "Removing RAM board" and "Removing MODEM card" described below).

**Caution:** Please follow directions carefully.  
Do not interchange screws in any part of the system.


### • Removing Battery Pack




**Figure 1**

1. Close the display panel.
2. Turn the computer upside down and place it on a flat surface.
3. While pushing the BATTERY RELEASE (in the direction of the arrow), push out the battery pack (in the direction of the arrow) by about 5mm.
4. Lift out the battery pack.

### • Removing RAM Board



**Figure 2**



**Figure 3**

1. Open the rear cover, and remove the two screws on the RAM board slot cover, then remove the RAM board slot cover. (Refer to Figure 2.)
2. Insert the front edge of the RAM board slot cover that you removed into the hole in the installed RAM board, and engage the slot cover with the RAM board. Next, keeping the slot cover horizontal, pull it slowly toward you. (Refer to Figure 3.)

## • Removing Modem Card




Figure 4

1. Close the display panel.
2. Turn the computer upside down and place it on a flat surface.
3. Remove the screw on the modem cover, carefully raise the modem cover and remove it. (Refer to Figure 4.)
4. Remove the screw on the modem and carefully raise the modem. (Refer to Figure 5.)
5. Carefully remove the flat cable from the connector. (Refer to Figure 6.)




Figure 5




Figure 6

## 4.1 Top Case




Figure 7

- (1) Remove the rubber cover at the back of the computer by using something like an ice pick, then remove the screw <A> (2.6 × 4 mm).




Figure 8

- (2) Open the display panel fully as shown in Figure 8, slowly raise the cover obliquely upward and remove it.
- (3) Remove two hinge covers by pressing them in the direction of arrows as shown in Figure 8.





Figure 9

- (4) Disconnect the LCD connectors (CN308, CN309) as shown in Figure 9.






Figure 10A




Figure 10B




Figure 10C




Figure 11




Figure 12

(5) Remove four screws <B> (2.6×12mm), then remove the Display Unit as shown in Figure 10A.

(6) Remove the Power/Battery LED PCB from the Top Case as shown in Figure 10C.

Note: The PCB can be removed by pushing the hook in the direction of <X> as shown in Figure 10C.

(7) Remove the flat cable of the Track Ball from the connector (CN301).\*

\*Note: When handling or using the track-ball, do not get the ball dirty. If the ball becomes soiled, it can be cleaned with water and a lintfree cloth.

Note: The flat cable can be removed by sliding its connector in the direction of <Y> as shown in Figure 10C.

(8) Remove one screw <C> (2.6×8mm) as shown in Figure 10B.

(9) Turn over the computer and remove three screws <D> (2.6×8mm), two screws <E> (2.6×6mm), and one screw <F> (2.6×24mm) as shown in Figure 11.

(10) Turn over the computer again. Then, carefully pull the sides of the top case outward and raise the top case to unlatch the side hooks. Disconnect the LED/Switch PCB connector (CN304) as shown in Figure 12.

\* Reassemble in reverse order.

## 4.2 Keyboard




Figure 13

- (1) After removing the top case (Figure 13), turn over the keyboard and then disconnect keyboard connector as shown in Figure 14.

Note: The flat cable can be removed by sliding its connector in the direction of <X> as shown in Figure 14.

\* Reassemble in the reverse order.




Figure 14 Keyboard Connector

## 4.3 Main PCB (Upper)




Figure 15

- (1) After removing the top case and the keyboard, remove two screws <A> (3×7mm), disconnect the connector (CN302) of Power/Battery LED PCB as shown in Figure 15.


- (2) Carefully disconnect PCB connectors (CN303, CN305) by using a flat head screwdriver as shown in Figure 16.

- (3) Disconnect Beeper connector (CN310) as shown in Figure 15.

**Caution:**

- Do not use excessive force when disconnecting the connectors.
- Do not bend the Main PCB (Upper), while removing it.

\* Reassemble in the reverse order.



Screwdriver Figure 16

## 4.4 Floppy Disk Drive (FDD)




Figure 17




Figure 18




Figure 19

- (1) After removing the top case, the keyboard, and the main PCB (Upper), remove two screws <A> ( $3 \times 4$  mm) as shown in Figure 17.

- (2) Gradually raise the front end of the FDD and then disconnect the FDD flat cable from connector (CN5) as shown in Figure 18.
- (3) Gradually disconnect the FDD flat cable from the connector mounted on the FDD.

Note: When connecting the FDD flat cable to the connectors on the FDD and the main PCB (Lower), be sure the conductive side of the cable is facing downward.

- (4) Remove four screws <B> ( $3 \times 4$  mm) from the FDD bracket and then remove the FDD bracket as shown in Figure 19.

\* Reassemble in the reverse order.

## 4.5 Main PCB (Lower)




Figure 20

- (1) After removing the top case, the keyboard, the main PCB (Upper), and the FDD, disconnect the Battery Pack Connector (CN13) and the HDD Cable Connector (CN6) as shown in Figure 20.
- (2) Remove six screws <A> ( $3 \times 7$  mm) and two PCB holding plates as shown in Figure 20.
- (3) Remove the plate spring as shown in Figure 20.




Figure 21

- (4) Gradually raise the rear end of the main PCB (Lower) and remove it from bottom cabinet.
- (3) Remove the connector frame from the main PCB (Lower) by removing two screws <B> (2.6 × 5 mm), four screws <C>, and two screws <D> as shown in Figure 21.

\* Reassemble in the reverse order.

## 4.6 Hard Disk Drive (HDD)




Figure 22

- (1) Close the display panel.
- (2) Turn the computer upside down and place it on a flat surface.
- (3) Remove screws <A> (2.6 × 24 mm) and <B> (2.6 × 8 mm) as shown in Figure 22.




Figure 23

- (4) Carefully raise the HDD and slide it over leftward about 3mm as shown in Figure 23.




Figure 24

- (5) Carefully raise the HDD as shown in Figure 24.




Figure 25




Figure 25A

- (6) Carefully remove the HDD cable from the HDD as shown in Figure 25.

Note: When connecting the HDD cable to the connector mounted on the HDD, be sure to connect the HDD cable as shown in Figure 25A.




Figure 26

- (7) Turn over the HDD and remove four screws <C> (3×4mm) and the HDD Lid as shown in Figure 26.

\*Reassemble in the reverse order.

## 4.7 LCD Unit




Figure 27

Figure 27A

Caution: When the display panel has been already removed from the top case, the display panel should be installed to both top and bottom cases.

Otherwise, the LCD unit could be damaged while opening the display panel.

- (1) Open the display panel fully as shown in Figure 27, then gently remove two screw plugs by pressing them with a flat head screwdriver and two screws <A> (2.6×4mm).

Notes: • The contrast control knob can not be removed from the display panel at this time. Thus, do not try to remove the contrast control knob.

• When inserting the screw plugs into the display panel, be sure the screw plugs are being inserted properly as shown in Figure 27A.




Figure 28

- (2) Firmly close the display panel.  
Then, gradually pull up the upper display case from the lower display case in the direction of arrows **A** as shown in Figure 28 and 28A.
- (3) Next, gradually pull up the upper case from the lower case in the direction of arrows **B** and **C** as shown in Figure 28.




Figure 28A




Figure 29

- (4) Raise the upper display case in the direction of arrow **D** and then slide it over in the direction of arrow **E** as shown in Figure 29.

Note: When reassembling, carefully latch four hooks **A** first and latch remaining hooks **B** as shown in Figure 30.




Figure 30





Figure 31




**Figure 32A**


(5) Remove four screws <A> and the LCD holding frames <B> and <F> as shown in Figure 32.

Note: When you need to remove the contrast control knob, take the following procedures:


- a) Peel off the tape near the contrast control PCB as shown in Figure 32A.
- b) Gradually pull out the contrast control PCB as shown in Figure 32B.
- c) Slide the contrast control knob to the "LOW" position as shown in Figure 32C.
- d) Gently pull out the contrast control knob from the LCD front panel while pushing the hook of the knob with a flat head screwdriver as shown in Figure 32C and 32D.



**Figure 32B**



**Figure 32C**      **Figure 32D**



**Figure 33**

(6) Raise the FL lamp in the direction of arrows <D> as shown in Figure 33.

(7) Carefully turn over the light leading panel as shown in Figure 34.

Note: Do not get the light leading panel stained with fingerprints and dust.

(8) Peel off two pieces of tape fixing LCD cable and insulation plate as shown in Figure 34.




Figure 34

(9) Disconnect the LCD cable connector from the LCD unit and remove the LCD unit as shown in Figure 35.

Note: Do not get the LCD unit stained with fingerprints and dust.  
When reassembling, place the LCD unit as shown in Figure 35A.

\* Reassemble in the reverse order.




Figure 35




Figure 35A

## 4.8 FL Lamp

- (1) After the disassembly step (7) of "4.7 LCD unit" is done, open the diffusion sheet as shown in Figure 36.




Figure 36

- (2) Carefully slide and take out the light leading panel the diffusion sheet as shown in Figure 37.

Notes: • Do not get the LCD unit and the light leading panel stained with fingerprints and dust.

- When reassembling, place the diffusion sheet inside the "L" shaped projections as shown in Figure 37A.




Figure 37




Figure 37A

- (3) Remove two screws <A>, then raise the FL inverter PCB as shown in Figure 38 and Figure 39.






Figure 38



**Figure 39**


- (4) Disconnect the FL lamp connector (CN902), then remove the FL lamp as shown in Figure 39.

Note: When reassembling, align the wires of the FL lamp as shown in Figure 39A.



**Figure 39A**


## 4.9 Replacing Diffusion Sheet Ass'y



**Figure 40**

- (1) After the disassembly step (2) of "4.8 FL Lamp" is done, carefully peel off the insulation sheet and the diffusion sheet ass'y from the light leading panel block as shown in Figure 40.


\*Note: Diffusion sheet ass'y includes both diffusion sheet and reflector.



**Figure 41**


(2) Place the new diffusion sheet ass'y on the LCD unit as shown in Figure 41.

Note: Refer to "Notes" described in page 4-12.




**Figure 42**

(3) Place the light leading panel as shown in Figure 42.



**Figure 42A**

(4) Place the FL lamp and align the wires of the FL lamp as shown in Figure 42 and Figure 42A.



**Figure 43**

(5) Install the LCD holding frames <B> and <F> with four screws <A> as shown in Figure 43.

(6) Stick the lamp reflector to the LCD reflector by pulling in the direction of arrow as shown in Figure 43.




Figure 44

- (7) Stick the insulation sheet as shown in Figure 44.

### 4.10 Track Ball




Figure 45

- (1) After the disassembly step (10) of “4.1 Top Case” is done, remove screw <A> as shown in Figure 45.

- (2) Remove two screws <B> as shown in Figure 45A.




Figure 45A

## 5. LCD Contrast Adjustment

### 5.1 Test Equipment

- |  |       |
|--|-------|
| (1) LCD Contrast Adjustment Disk (P/N: DFVV91C0005)..... | 1 pc. |
| (2) AC Adapter.....                                      | 1 pc. |
| (3) Main Battery .....                                   | 1 pc. |
- (Note: Be sure that Main Battery Pack is fully charged.)

### 5.2 Adjustment Methods

**Note:**

The following adjustment should be performed at an environmental temperature of 77°F (25°C).

**Preparation:**

- Attach the fully charged battery pack.
- Connections should be made as shown in Figure 1.
- Slide the LCD contrast control knob as shown in Figure 2.




Figure 1





Figure 2

**Procedure:**

- (1) Insert the LCD contrast adjustment disk to FDD.
- (2) Press the power switch to turn ON the computer and press the reset button.
- (3) Set the backlight brightness into "High".  
(Select brightness by using Fn + F6 keys.)
- (4) Confirm that the screen displays test graphic pattern as shown in Figure 3 on next page.
- (5) Carefully adjust the screen contrast by pressing "←" and "→" keys to obtain the best contrast.
- (6) Press "Space" key.
- (7) Press "Y" key. (Or press "N" key if readjustment is required and repeat from step (5).)
- (8) The LCD screen displays as shown in Figure 4 on next page.
- (9) Press any key.
- (10) The LCD screen displays as shown in Figure 5 on next page.
- (11) LCD contrast adjustment is completed and the computer will be rebooted. Thus, remove the LCD contrast control disk from the FDD.

**Note:**

If LCD contrast adjustment fails, be sure whether a +12Vdc is supplied from pin 1 of IC7 (Regulator) or not. The +12Vdc is output when "Any Key" is pressed at step (9) in this adjustment.



**Figure 3**

```
A>REM ** write to flash ROM **  
A>FLASHS FLASH1.BIN
```

```
Boot block 8 KB is OK.  
PMAN disabled.  
Shadow and cache disabled.  
Write to ROM CS enabled.  
Flash BIOS ID confirmed.  
12V enabled.
```

```
Ready to program. Be sure 12V is under GA2 control.  
Press any key when ready
```


**Figure 4**

```
Erasing & programming FLASH...please wait
```


**Figure 5**

## 6. Schematic Diagrams/Parts Location/Replacement Parts List

### 6.1 Wiring Connection Diagram




6.2 Schematic Diagrams (1) Main PCB (Upper), CPU/Co-processor Circuit (Sheet No. 1 of 10)




Note: 3/11F  
 Grid Location  
 Sheet No.

Note:  
 " " or " " denotes OUTPUT  
 " " or " " denotes INPUT  
 " " denotes BIDIRECTIONAL


(2) Main PCB (Upper), DRAM and Keyboard Interface Circuits (Sheet No. 2 of 10)



(3) Main PCB (Upper), VGA Circuit (Sheet No. 3 of 10)




(4) Main PCB (Upper), VRAM and Frame Memory Circuits (Sheet No. 4 of 10)




Note: 3/11F  
 → Grid Location Sheet No.  
 Note: " " or " " denotes OUTPUT  
 " " or " " denotes INPUT  
 " " denotes BIDIRECTIONAL


(5) Main PCB (Lower), FLASH Memory (BIOS) and I/O Subsystem Circuits (Sheet No. 5 of 10)




(6) Main PCB (Lower), Keyboard Controller and SKBE Circuits (Sheet No. 6 of 10)





(7) Main PCB (Lower), FDC, Parallel Port, and GA2 Circuits (Sheet No. 7 of 10)




(8) Main PCB (Lower), Power Control Circuit (Sheet No. 8 of 10)



(9) Main PCB (Lower), Connector Circuit (Sheet No. 9 of 10)




(10) Power/Battery LED PCB and LED/Switch PCB (sheet No. 10 of 10)



### 6.3 Printed Circuit Board and Parts Locations

#### Main PCB (Upper)






**Power/Battery LED PCB, LED/Switch PCB and Contrast Control PCB**


**Power/Battery LED PCB**

Top View




**LED/SWITCH PCB**

Top View




**CONTRAST CONTROL PCB**

Top View



# 6.4 Exploded View



## 6.5 Replacement Parts List (Mechanical, Accessories, Packing and Electrical)

NOTE: 1. Important safety notice.

Components identified by  $\Delta$  mark have special characteristics important for safety.  
When replacing any of these components, use only manufacturer's specified parts.

REF. No. AND AREA	PART NO.	DESCRIPTION	QTY
<b>MAIN BLOCK UNITS</b>			
E 1	DFWV48C198Z	Ass' y, PCB, MAIN(UPPER)	NLA 1
E 1-1	DFJS68R24ZA	SOCKET, 68-PIN, PLCC IC(IC303, CO-PROCESSOR)	1
E 1-2	DFMX0281ZA	SHEET, SLIDE, KEYBOARD MEMBRANE	1
E 1-3	DFMX0278ZA	SHEET, INSULATION	1
E 1-4	DFHG333ZA	SPACER, RUBBER, TRACK BALL	1
E 1-5	DFMX0280ZA	SHEET, PROTECTOR, CABLE, FDD	1
E 1-6	DFMX0249ZB	SHEET, INSULATION, TRACK-BALL	1
E 2	DL3U10510CAA	Ass' y, PCB, MAIN(LOWER)	NLA 1
E 3	DL3U40510CAA	Ass' y, PCB, LED/SWITCH	NLA 1
E 4	DL3U20510CAA	Ass' y, PCB, POWER/BATT LED	NLA 1
E 5	DL3U10484AAA	Ass' y, CONTRAST CONTROL, PCB	NLA 1
E 6	DFAFCB17AY	BEEPER	1
E 7 $\Delta$	DFJG052YA-M	Ass' y, FDD	1
E 8 $\Delta$	DFWV48C194Z	Ass' y, FL INVERTER PCB	1
E 9 $\Delta$	DFJH003ZA-C	HDD, 80MB, CP-2084	1
E10 $\Delta$	(M) ESU54TM404BK	Ass' y, KEYBOARD(U.S.A.)	1
	(E) ESU54TM405BA	Ass' y, KEYBOARD(ENGLISH)	
	(F) ESU54TM405CA	Ass' y, KEYBOARD(FRENCH)	
	(G) ESU54TM405AA	Ass' y, KEYBOARD(GERMAN)	
	(SW) ESU54TM405FA	Ass' y, KEYBOARD(SWEDISH)	
E11	EMU-15901	Ass' y, TRACK-BALL	1
E11-1	DFWV65C0223	LID, TRACK-BALL	1
E11-2	DFWV65C0224	BALL, TRACK-BALL	1
E12	DFWV08A025ZA	Ass' y, LCD UNIT	1
<b>MECHANICAL PARTS</b>			
K 1	(M) DFWV80A0127	Ass' y, CABINET, TOP	1
	(E, SW) DFWV80A0128		
	(F, G) DFWV80A0129		
K 2 $\Delta$	(M) DFWV80C0237	Ass' y, CABINET, BOTTOM	1
	(E, F, G) DFWV80C0241		
	(SW) DFWV80C0244		
K 2-1	DFHG332YA	FOOT, RUBBER, BOTTOM CABINET	2
K 3	DFWV60B0005	Ass' y, LID, HDD HOUSING	1
K 4	DFWV82A0062	Ass' y, LID, MODEM HOUSING	1
K 5	DFWV82A0063	Ass' y, LID, EXTENSION	1
K 6	DFWV82A0064	Ass' y, LID, EXTERNAL CONNECTORS	1
K 6-1	DFHG954ZA-0	FOOT, RUBBER, CONNECTOR LID	2
K 7	DFWV80C0238	Ass' y, CABINET, FRONT, LCD	1
K 8	DFWV52H0004	Ass' y, PANEL, LIGHT LEADING	1
K 9	DFWV65A0196	Ass' y, FRAME, LCD HOLDING F	1
K10	DFWV65A0195	Ass' y, FRAME, LCD HOLDING B	1
K11	DFWV65A0197	Ass' y, FRAME, REINFORCEMENT, HINGE, RIGHT	1
K12	DFWV84A0081	Ass' y, CABINET, REAR, LCD	1
K13	DFBD0043ZA-1	KNOB, LCD CONTROL	1
K14	DFHR5237ZA-1	KNOB, LCD HOLD	2
K15	DFBH1025ZA	HINGE, LEFT	1
K16	DFBH1026ZA	HINGE, RIGHT	1
K17	DFMD1055ZB	FRAME, REINFORCEMENT, HINGE, LEFT	1
K18	DFJS01Z71ZAV	CABLE, LCD	1
K19	DFACO010ZAW	LAMP, BACKLIGHT, LCD	1
K20	DFMX0254ZA	SHEET, INSULATOR-2, LCD	1
K21	DFHR9010ZA	SLEEVE, LCD	1
K22	DFHG406ZA	TUBE, STOPPER, SPRING	2
K23	DFHG944ZA-1	PLUG, SCREW, RUBBER	2
K24	DFME0074ZA-0	HOLDER, LCD	2
K25	DFUW0044ZB	SPRING, LCD LOCK	2
K26	DFHR9005ZA-K	CLAMP, CABLE	1
K27	DFMX0273YA	PLATE, FIXER, CABLE	1
K28 (NOT USED)			
K29	XSB26+4	SCREW, M2.6 x 4mm	6
K30	YVN26+C4	SCREW, M2.6 x 4mm	4

REF. No. AND AREA	PART NO.	DESCRIPTION	QTY
K31	YVN26+C5FN	SCREW, M2.6 x 5mm	2
K32	DFKE0217ZA-0	COVER, HINGE, LEFT	1
K33	DFKE0218ZA-0	COVER, HINGE, RIGHT	1
K34	DFMD3019ZA	FRAME, PCB HOLD	2
K35	DFMD3020ZA	FRAME, RAM CARD HOLD	1
K36	DFMX0247ZA	SHEET, INSULATION, MAIN PCB	1
K37	DFJC9911ZAC	Ass' y, BATTERY TERMINAL	1
K38	DFGX0101ZA	PLATE, ORNAMENT, BOTTOM CABINET	1
K39	DFBD0045ZA-1	KNOB, BATTERY	1
K40	DFBD0046ZA-1	KNOB, CONNECTOR LID	1
K41	DFWV65A0198	Ass' y, FRAME, CONNECTOR	1
K42	DFUW0045ZB	SPRING, UPLIFT, CONNECTOR LID	2
K43	DFMD1059ZA	STAY, CONNECTOR LID, LEFT	1
K44	DFMD1060ZA	STAY, CONNECTOR LID, RIGHT	1
K45	DFMD3017ZB	SUSTAINER, CONNECTOR LID, LEFT	1
K46	DFMD3018ZB	SUSTAINER, CONNECTOR LID, RIGHT	1
K47	DFMD3022ZA	PLATE, PROTECTION, CO-PROCESSOR	1
K48	DFMD2041ZA	FRAME, FDD HOLD	1
K49	DFHG329ZA-1	MASK, RUBBER, SCREW	1
K50	DFJS01Z70YA	CABLE, HDD	1
K51	DLJS0022A02A	CABLE, LED/SWITCH PCB	1
K52	DFJE26A038BS	CABLE, FDD	1
K53	DLJS0022A03A	Ass' y, CABLE(POWER/BATT LED)	1
K54	DFUS0146ZA	SPRING, BATTERY EJECT	1
K55	DFUW0043ZB	SPRING, LOCK, EXTERNAL CONNECTOR	1
K56	XSB26+24FZ	SCREW, M2.6 x 24mm	1
K57	XSB26+8FZ	SCREW, M2.6 x 8mm	6
K58 (NOT USED)			
K59	YVN26+C5FN	SCREW, M2.6 x 5mm	2
K60	YVN26+J12	SCREW, M2.6 x 12mm	4
K61	YVN3+J7	SCREW, M3 x 7mm	10
K62	XSB2+4	SCREW, M2 x 4	1
K63	XSB2+5FN	SCREW, M2 x 5mm	5
K64	XSS26+4FZ	SCREW, M2.6 x 4mm	1
K65	YVN26+C5FN	SCREW, M2.6 x 5mm	2
K66	XWA3BFN	WASHER	4
K67	XSS26+6FZ	SCREW, EXTERNAL CONNECTORS	2
K68	XSB3+4	SCREW, M3 x 4mm	6
K69	XSS3+4FZ	SCREW, M3 x 4mm	4
K70	DFHE5031ZA	SCREW, HEXAGONAL HEAD	2
K71	DFHE5020ZB	SCREW, LID, EXTERNAL CONNECTOR	4
K72	DFHR7180ZB	SHEET, DIFFUSION, LCD	1
K73	DFHM0115ZA	SPRING, PLATE, CONNECTOR	2
K74	DFHM0116ZA	SPRING, PLATE, CONNECTOR, SERIAL	1
K75	DFGL0019ZA	PANEL, LIGHT LEADING, FUNCTION LED	1
K76	DFGL0020ZA	PANEL, LIGHT LEADING, POWER/BATT LED	1
K77	DFBC0114ZA-1	BUTTON, POWER ON-OFF	1
K78	DFBC0115ZA-1	BUTTON, TRACK-BALL	1
K79 (NOT USED)			
K80	DFHE5027ZA	SCREW, EXTERNAL CONNECTOR	4
K81 (NOT USED)			
K82	XQDNF2+A4FZ	SCREW, M2 x 4mm	4
K83	DFNW3102YA	WASHER	4
K84 (NOT USED)			
K85 (NOT USED)			
K86	DFUS0154ZA	SPRING, HOOK, LCD L	1
K87	DFUS0155ZA	SPRING, HOOK, LCD R	1
K88	DFUS0156ZA	SPRING, HOOK	2
K89	DFMX0285ZA	SHEET, INSULATION	1
K90 (NOT USED)			
K91	DFMX0286ZA	SHEET, PROTECTION, HDD CABLE	2
K92	DFMD1066ZA	SPRING, PLATE, LCD	1
K93 (NOT USED)			
K94 (NOT USED)			
K95	DFHR9011ZA	CUSHION, FERRITE	1
K96	DFHR7206ZA	SHEET, FERRITE	1
K97	DFDR9002ZC	WASHER	1

REF. No. AND AREA	PART NO.	DESCRIPTION	Q' TY	
<b>ACCESSORIES</b>				
A 1    Δ	(M, E, F, G)	CF-AA186M1	AC ADAPTER, INPUT/110-240V, OUTPUT/23Vdc 1.25A	1
	(SW)	CF-AA186M2		
A 2    Δ	(M, SW)	DFJAO033ZAKK	AC CABLE, 125V, 1250W(for AC Adapter)	1
	(E)	DFJAO42BKK		
	(G, F)	DFJAO032ZAKK		
A 3	(M, E, SW)	DFJN309ZA	DISK, SYSTEM (DISK1, INSTALLATION)	1
	(F)	DFJN307ZA		
	(G)	DFJN305ZA		
A 4	(M, E, SW)	DFJN310ZA	DISK, UTILITY (DISK2, INSTALLATION)	1
	(F)	DFJN308ZA		
	(G)	DFJN306ZA		
A 5	(M, E, F, SW)	DFQX2378ZA	MANUAL, USER'S GUIDE(ENGLISH)	1
	(SW)	DFQX2383ZA	MANUAL, USER'S GUIDE(SWEDISH)	
	(G)	DFQX2379ZA	MANUAL, USER'S GUIDE(GERMAN)	
	(M, F)	DFQX2380ZA	MANUAL, USER'S GUIDE(FRENCH)	
A 6		DFQX2384ZA	MANUAL, QUICK REFERENCE	1
A 7		DFQX2392ZA	MANUAL, REFERENCE GUIDE	1
A 8		DFQX2396ZA	MANUAL, USER'S GUIDE, WINDOWS	1
A 9		DFQX2400ZA	MANUAL, READ ME, FIRST	1
A10	(M, E, F, SW)	DFQX1134ZA	MANUAL, ADDENDUM (ENGLISH)	1
A11	(E)	DFQX1135ZA	LEAFLET, AC PLUG	1
A12	(M, E, SW)	DFWV91C0006	DISK, WINDOWS, DISK SET 1-5	1
	(F)	DFWV91C0007		
	(G)	DFWV91C0008		
<b>PACKING MATERIALS</b>				
P1		DFPK0557ZA	PACKING CASE	1
P2		DFPN0445ZA	HOLDER-A	1
P3		DFPN0444ZA	CUSHION	4

REF.No. AND AREA	PART NO.	DESCRIPTION	Q'TY
<b>MAIN PCB(UPPER)</b>			
E 1	DFWW48C198Z	Ass'y, PCB, MAIN(UPPER)	NLA 1
E 1-1	DFJS68R24ZA	SOCKET, 68-PIN, PLCC IC(C303, CO-PROCESSOR)	1
E 1-2	DFMX0281ZA	SHEET, SLIDE, KEYBOARD MEMBRANE	1
E 1-3	DFMX0278ZA	SHEET, INSULATION	1
E 1-4	DFHG333ZA	SPACER, RUBBER, TRACK BALL	1
E 1-5	DFMX0280ZA	SHEET, SUPPORT, CABLE, FDD	1
E 1-6	DFMX0249ZB	SHEET, INSULATION, TRACK-BALL	1
C301, 302	ECEVOJV101SP	CAPACITOR, ELECTRYTIC, Chip, 100uF, +/-20%, 6.3V	2
C303	DCUGIC105ZFL	CAPACITOR, CERAMIC, CHIP, 1uF, +80/-20%, 16V	1
C304-319	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	16
C320	ECEVOJV101SP	CAPACITOR, ELECTRYTIC, Chip, 100uF, +/-20%, 6.3V	1
C321, 322	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	2
C323	DCUA1E103KRR	CAPACITOR, CERAMIC, CHIP, 25V, 0.01uF, +/-10%, 25V	1
C324	DCUA1H120JCR	CAPACITOR, CERAMIC, CHIP, 12PF, +/-5%, 50V	1
C325	DCUA1E103KRR	CAPACITOR, CERAMIC, CHIP, 25V, 0.01uF, +/-10%, 25V	1
C326	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C327	DCUA1H120JCR	CAPACITOR, CERAMIC, CHIP, 12PF, +/-5%, 50V	1
C328	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C329, 330	DCUA1E103KRR	CAPACITOR, CERAMIC, CHIP, 25V, 0.01uF, +/-10%, 25V	2
C331	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C332	DCUA1E103KRR	CAPACITOR, CERAMIC, CHIP, 25V, 0.01uF, +/-10%, 25V	1
C333-338	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	6
C339	ECEVOJV330SR	CAPACITOR, ELECTRYTIC, Chip, 33uF, 6.3V	1
C349	DCUA1H511JCR	CAPACITOR, CERAMIC, CHIP, 510PF, +/-5%, 50V	1
C350-353	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	4
C354	DCUA1E102KRR	CAPACITOR, CERAMIC, CHIP, 0.001uF, +/-10%, 25V	1
C355, 356	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	2
C357	ECEVOJV330SR	CAPACITOR, ELECTRYTIC, Chip, 33uF, 6.3V	1
C358-362	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	5
C363-377	DCUA1H101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 50V	15
C378-382	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	5
C383-402	DCUA1H101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 50V	20
C403	ECEVOJV330SR	CAPACITOR, ELECTRYTIC, Chip, 33uF, 6.3V	1
C404	DCUA1H101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 50V	1
C405-414	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	10
CN301	DFJS04N23ZAJ	CONNECTOR, 4-PIN, TRACK-BALL, FEMALE	1
CN302	DFJPO5C78ZAO	CONNECTOR, 5-PIN, POWER INDICATOR, MALE	1
CN303	DFJS60D42ZA	CONNECTOR, 60-PIN, FEMALE	1
CN304	DFJPO7C77ZAO	CONNECTOR, 7-PIN, POWER SWITCH PCB, MALE	1
CN305	DFJS80D42ZA	CONNECTOR, 80-PIN,	1
CN306	DFJS50D44ZA	CONNECTOR, 50-PIN, EXT RAM, FEMALE	1
CN308	DFJPI4C78ZAO	CONNECTOR, 14-PIN, LCD, MALE	1
CN309	DFJPO6C77ZAO	CONNECTOR, 6-PIN, LCD, MALE	1
CN310	DFJPO2C83ZAB	CONNECTOR, 2-PIN, BUZZER, MALE	1
CN312	DFJS20N24ZAJ	CONNECTOR, 20-PIN, KEYBOARD, FEMALE	1
D301	DEDRB400DT97	DIODE, SCHOTTKY BARRIER, (2.9 x 1.6 x 1.1), RB400D	1
D302, 303	DEDDA116T97	DIODE, SWITCHING, SI EPITAXIAL PLANAR, Chip	2
FL301, 302	DEANFM41R470	FILTER,	2
FL303, 304	DEA61R0361TL	FILTER,	2
IC301	DA7S04FT85LO	IC, ONE GATE, INVERTER, TC7S04FTE85L	1
IC302	DAKU386SL25I	IC, CPU(80386SL), 25MHz, KU80386SL-25	1
IC304, 305	DA5863AJ25TS	IC, CACHE, 64K bit SRAM, 25ns, 28PIN, CXK5863AJ-25-T6	2
IC306-309	DA4440AJ8LTM	IC, 4M bit DRAM, 80ns, 20PIN, M5M4400AJ-8L-LO	4
IC310	DA910401SXOF	IC, PROGRAMMABLE FREQUENCY GENERATOR, 14-PIN, AV9104-01	1
IC311	DA9127-01XOF	IC, CLOCK GENERATOR, AV9127-01	1
IC313	DAACO4SJLN	IC, HEX INVERTERS, C-MOS, 14-PIN, 74ACO4SJL	1
IC314	DAGD6410-XV	IC, VGA CONTROLLER, 160PIN, GD6410	1
IC315	DALM334MT-N	IC, CONSTAND CURRENT, LM 334M-63	1
IC316-318	MN2C4256AJ7T	IC, MN2C4256AJ7T	3
IC319, 320	DAACT245SJLN	IC, OCTAL BUS TRANCEIVER, C-MOS, TTL LEVEL OUTPUT	2
IC321	DA7220J4KW	IC, GATE ARRAY, SLA7220J4K	1
IC323	DAACO4SJLN	IC, HEX INVERTERS, C-MOS, 14-PIN, 74ACO4SJL	1
IC324	DAHCO2AFTO	IC, QUAD NOR GATES, CMOS, 14PIN, TC74HC02AF	1
IC325	DAHCT74AFTO	IC, DUAL D-FLIP-FLOP, CMOS, 14-PIN	1
IC326	DAHCO8AFT	IC, QUAD AND GATES, CMOS 14PIN	1
JP306, 308	DBJ6GMJROOVE	JUMPER, 0ohm, Chip	2
L301, 302	ELJFAI01KF	FERRITE BEAD	2

REF. No. AND AREA	PART NO.	DESCRIPTION	Q' TY
L303-340	DDB5Z005-L	FERRITE BEAD	38
Q801	2SB1260T100Q	TRANSISTOR, PNP TYPE, Chip	1
Q902	DETCl14EKT97	TRANSISTOR, RESISTOR BUILT-IN, CHIP, (2.9 x 1.9 x 1.1), DTC144EK	1
R306, 307	DBJ6GMJ330VE	RESISTOR, Thick Film, CHIP, 33ohm, +/-5%, 1/10W	2
R308	DBJ6GMJ472VE	RESISTOR, Thick Film, CHIP, 4.7Kohm, +/-5%, 1/10W	1
R311-315	DBJ6GMJ330VE	RESISTOR, Thick Film, CHIP, 33ohm, +/-5%, 1/10W	5
R317	DBJ6GMJ5R1VE	RESISTOR, Thick Film, CHIP, 5.1ohm, +/-5%, 1/10W	1
R318	DBJ6GMJ152VE	RESISTOR, Thick Film, CHIP, 1.5Kohm, +/-5%, 1/10W	1
R319	DBJ6GMJ5R1VE	RESISTOR, Thick Film, CHIP, 5.1ohm, +/-5%, 1/10W	1
R320	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R321-323	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	3
R324	DBJ6GMJ330VE	RESISTOR, Thick Film, CHIP, 33ohm, +/-5%, 1/10W	1
R325, 326	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	2
R335, 337	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	2
R338	ERJ6GEYF200V	RESISTOR, Thick Film, CHIP, 20ohm, +/-1%, 1/10W	1
R339	DBJ6GMJ201VE	RESISTOR, Thick Film, CHIP, 200ohm, +/-5%, 1/10W	1
R340-342	DBJ6GMJ151VE	RESISTOR, Thick Film, CHIP, 150ohm, +/-5%, 1/10W	3
R353	DBJ6GMJ222VE	RESISTOR, Thick Film, CHIP, 2.2Kohm, +/-5%, 1/10W	1
R354	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R355	DBJ6GMJ680VE	RESISTOR, Thick Film, CHIP, 68ohm, +/-5%, 1/10W	1
R357	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R358	DBJ6GMJ331VE	RESISTOR, Thick Film, CHIP, 330ohm, +/-5%, 1/10W	1
R359	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R360	DBJ6GMJROOVE	JUMPER, 0ohm, Chip	1
R362	DBJ6GMJ680VE	RESISTOR, Thick Film, CHIP, 68ohm, +/-5%, 1/10W	1
R363, 371-375	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	6
R376	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R377	DBJ6GMJ472VE	RESISTOR, Thick Film, CHIP, 4.7Kohm, +/-5%, 1/10W	1
RA301-307	EXBS8V330J	RESISTOR ARRAY, 33ohm x 4	7
RA308	EXBS8V102J	RESISTOR ARRAY, 1Kohm x 4	1
RA309, 310	EXBS8V473J	RESISTOR ARRAY, 47Kohm x 4	2
RA311-313	EXBS8V101J	RESISTOR ARRAY, 100ohm x 4	3
RA314, 315	EXBS8V103J	RESISTOR ARRAY, 10Kohm x 4	2
RA318, 319	EXBS8V473J	RESISTOR ARRAY, 47Kohm x 4	2
RA320	EXBS8V680J	RESISTOR ARRAY, 68ohm x 4	1
RA321, 322	EXBS8V473J	RESISTOR ARRAY, 47Kohm x 4	2
RA323-325	EXBS8V330J	RESISTOR ARRAY, 33ohm x 4	3
X301	DECU14318L1N	CRYSTAL, 14.318MHz	1

### MAIN PCB(LOWER)

REF. No. AND AREA	PART NO.	DESCRIPTION	Q' TY
E 2	DL3U10510CAA	Ass'y, PCB, MAIN(LOWER)	NLA 1
BT1	VL3032/1HM5	BATTERY, VANADIUM, 3V, 100mAH, VL3032/1HM5, (UPPER)	1
BT2	VL3032/1HF5	BATTERY, VANADIUM, 3V, 100mAH, VL3032/1HF5, (LOWER)	1
C 1-5, 7-10	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	9
C 11	DCUA1H680JCR	CAPACITOR, CERAMIC, CHIP, 680PF, +/-5%, 25V	1
C 12-15	DCUG1C105ZFL	CAPACITOR, CERAMIC, CHIP, 1uF, +80/-20%, 16V	4
C 16-18	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	3
C 20, 22, 23, 26, 27	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	5
C 32-34	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	3
C 35	ECEVICV100SR	CAPACITOR, ELECTRYTIC, Chip, 10uF, +/-20%, 16V	1
C 36	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C 37-44	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	8
C 45	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C 46-54	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	9
C 57	ECWU1C273JA5	CAPACITOR, FILM, CHIP, 0.027uF, +/-5%, 16V	1
C 58	ECWU1C473JA5	CAPACITOR, FILM, CHIP, 0.047uF, +/-5%, 16V	1
C 59	DCUA1E102KRR	CAPACITOR, CERAMIC, CHIP, 0.001uF, +/-10%, 25V	1
C 60, 61	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	2
C 62	ECEVOJV330SR	CAPACITOR, ELECTRYTIC, Chip, 33uF, 6.3V	1
C 63, 64	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	2
C 65	ECEVOJV101SP	CAPACITOR, ELECTRYTIC, Chip, 100uF, +/-20%, 6.3V	1
C 66-70	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	5
C 71	DCUA1E102KRR	CAPACITOR, CERAMIC, CHIP, 0.001uF, +/-10%, 25V	1
C 72	DCUG1C105ZFL	CAPACITOR, CERAMIC, CHIP, 1uF, +80/-20%, 16V	1
C 73	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	1
C 74	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C 75	DCUA1H120JCR	CAPACITOR, CERAMIC, CHIP, 12PF, +/-5%, 50V	1
C 76	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C 77-79	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	3


REF. No. AND AREA	PART NO.	DESCRIPTION	Q'TY
C 80	DCUA1H120JCR	CAPACITOR, CERAMIC, CHIP, 12PF, +/-5%, 50V	1
C 81	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	1
C 82	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	1
C 83-87	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	5
C 88-95	DCUA1E101JCR	CAPACITOR, CERAMIC, CHIP, 100PF, +/-5%, 25V	8
C 96	DCUA1E103KRR	CAPACITOR, CERAMIC, CHIP, 25V, 0.01uF, +/-10%, 25V	1
C 97, 98	DCUA1E102KRR	CAPACITOR, CERAMIC, CHIP, 0.001uF, +/-10%, 25V	2
C 99	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C100	DCUA1E103KRR	CAPACITOR, CERAMIC, CHIP, 25V, 0.01uF, +/-10%, 25V	1
C101	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C102	ECEV1EVI00SP	CAPACITOR, ELECTROLYTIC, Chip, 10uF, +/-20%, 25V	1
C103	ECEV0JV470SP	CAPACITOR, ELECTROLYTIC, Chip, 47uF, +/-20%, 6.3V	1
C104-108	DCUG1C105ZFL	CAPACITOR, CERAMIC, CHIP, 1uF, +80/-20%, 16V	5
C109-111	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	3
C112, 113	ECEV0JV470SP	CAPACITOR, ELECTROLYTIC, Chip, 47uF, +/-20%, 6.3V	2
C114	DCUG1C105ZFL	CAPACITOR, CERAMIC, CHIP, 1uF, +80/-20%, 16V	1
C115-118	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	4
C119	DCU01E475ZFY	CAPACITOR, CHIP, 4.7uF, +80/-20%, 25V	1
C120	ECEV1EV330SP	CAPACITOR, ELECTROLYTIC, Chip, 33uF, +/-20%, 25V	1
C121-124	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	4
C125-128	DCUG1C105ZFL	CAPACITOR, CERAMIC, CHIP, 1uF, +80/-20%, 16V	4
C130	DCUA1E104ZFR	CAPACITOR, CERAMIC, CHIP, 0.1uF, +80/-20%, 25V	1
C131, 132	ECEV0JV101SP	CAPACITOR, ELECTROLYTIC, Chip, 100uF, +/-20%, 6.3V	2
C133	DCUA1E103KRR	CAPACITOR, CERAMIC, CHIP, 25V, 0.01uF, +/-10%, 25V	1
C134	ECEV1CV220SP	CAPACITOR, ELECTROLYTIC, Chip, 22uF, +/-20%, 16V(5.4 x 6.6 x 6.6)	1
C135	DCUG1C105ZFL	CAPACITOR, CERAMIC, CHIP, 1uF, +80/-20%, 16V	1
CN 1	DFJS200D43ZA	CONNECTOR, 200-PIN, EXTENSION BOX, FEMALE	1
CN 2	DFJS18N29ZA	CONNECTOR, 18-PIN, MODEM, FEMALE	1
CN 3	DFJP09E19ZAD	CONNECTOR, 9-PIN, RS-232C, MALE	1
CN 4	DFJS25E17ZAD	CONNECTOR, 25-PIN, PARALLEL, FEMALE	1
CN 5	DFJS26N13ZAW	CONNECTOR, 26-PIN, FDD FEMALE	1
CN 6	DFJP44C70YA	CONNECTOR, 44-Pin, HDD, MALE	1
CN 7	DFJS06G08ZBH	EXTERNAL KEYBOARD JACK, 6-PIN, FEMALE	1
CN 8	DFJS06G08ZBH	EXTERNAL KEYBOARD JACK, 6-PIN, FEMALE	1
CN 9	DFJP60D34ZA	CONNECTOR, 60-PIN, STACK2, MALE	1
CN10	DFJP80D34ZA	CONNECTOR, 80-PIN, STACK1, MALE	1
CN11	DFJS15E12XA	CONNECTOR, 15-PIN, VGA FEMALE	1
CN12	DFJJB3Z11ZAH	CONNECTOR, DC-IN	1
CN13	RJP4G9YA	CONNECTOR, 4-PIN, BATTERY	1
D 1, 2	DEDSB0703CTA	DIODE, SCHOTTKY BARRIER	2
D 3	DEDRB705DT47	DIODE, SCHOTTKY BARRIER, (2.9 x 1.6 x 1.1), RB705D	1
D 5	DEDDA116T97	DIODE, SWITCHING, SI EPITAXIAL PLANAR, Chip	1
D 6	DEDRB420DT97	DIODE, SCHOTTKY BARRIER, (2.9 x 1.6 x 1.1), RB420D	1
D 7	DEDRLZ110ATE	DIODE, ZENNER, LEADLESS, (1.4 x 3.4), RLZ11	1
D 8	DEDDA116T97	DIODE, SWITCHING, SI EPITAXIAL PLANAR, Chip	1
D 9	DEDIMN10T109	DIODE ARRAY, SWITCHIN(2.9 x 1.6 x 1.1), IMN10	1
D10	DED10QS04TR	DIODE, SCHOTTKY BARRIER,	1
D11	DED30QS04FTF	DIODE, SCHOTTKY BARRIER,	1
D12	DEDIMN10T109	DIODE, Chip, Triple, Switching, (2.9 x 1.6 x 1.1), IMN10	1
D13, 14	DEDRLZ062ATE	DIODE, ZENNER, LEADLESS, (1.4 x 3.4), RLZ6.2	2
D15	DEDRLZ200ATE	DIODE, ZENNER, LEADLESS, (1.4 x 3.4), RLZ20	1
D16	DEDRLZ110ATE	DIODE, ZENNER, LEADLESS, (1.4 x 3.4), RLZ11	1
D17, 18	DEDHZKL4BLTR	DIODE, HITACHI, EZH4ALLTC	2
D19	DEDDA116T97	DIODE, SWITCHING, SI EPITAXIAL PLANAR, Chip	1
D20	DEDRB420DT97	DIODE, SCHOTTKY BARRIER, (2.9 x 1.6 x 1.1), RB420D	1
D21	DEDRB705DT47	DIODE, SCHOTTKY BARRIER, (2.9 x 1.6 x 1.1), RB705D	1
D22	DEDHZ4ALL	DIODE, ZENNER	1
F1 Δ	XBAD0800HFS	FUSE, FAST BLOW, 0.8A, 125V 7.5mm(L) x 2.6mm(H) WITH PIG TAIL	1
F2 Δ	XBAD5000HFS	FUSE, FAST BLOW, 5A, 125V 7.5mm(L) x 2.6mm(H) WITH PIG TAIL	1
F4 Δ	DFAHMCPO400T	FUSE, IC PROTECTOR,	1
F5 Δ	XBAD0250HFS	FUSE, FAST BLOW, 250mA, 125V 7.5mm(L) x 2.6mm(H) WITH PIG TAIL	1
FL1	DEANFM41R470	FILTER	1
FL2, 3, 4	DEAG1R0361TL	FILTER,	3
IC 1	DA708BFOEW	IC, GATE ARRAY, SLA708BFOE	1
IC 3	DAKU82360SLI	IC, PERIPHERAL I/O, KU82360SL	1
IC 4	DARH5VA40AAR	IC, RESET SIGNAL GENERATOR, RH5VA40AA, 4.0V	1
IC 5	DALT1137CSXU	IC, RS-232C DRIVER/RECEIVER, LT1137CS	1
IC 6	DFWV06B0072Z	IC, FLASH MEMORY, BIOS, 32PIN, N28F001BX-T-120	1
IC 7	DATL750L12TT	IC, REGULATOR, TL750L12CD	1

REF. No. AND AREA	PART NO.	DESCRIPTION	QTY
IC 8	DAACT244SJLN	IC, OCTAL BUFFERS/LINE DRIVERS/RECEIVERS, 20PIN, 74ACT244SJL	1
IC 9	DABC244FTO	IC, OCTAL BUFFER, LINE DRIVER/RECEIVER, Bi-CMOS	1
IC 10	DADP8473V-N	IC, FDC, 52PIN, DP8473V	1
IC 11	DA7S04FT85LO	IC, ONE GATE, INVERTER, TC7S04FTE85L	1
IC 12	DA80C42-597D	IC, KB CONTROLLER, UPD80C42GB-597-3B4	1
IC 13	DAHCI26AFTO	IC, QUAD TRI-STATE BUFFER, 14-PIN, C-MOS, TC74HC126AF(TP2)	1
IC 14	DAHCO4AFTO	IC, HEX INVERTERS, C-MOS, 14-PIN, TC74HC04AF	1
IC 15	DAHCI4AFTO	IC, HEX INVERTING SCHMITT TRIGGERS, 14-PIN, C-MOS	1
IC 16	DAHC27AFTO	IC, 3-INPUT NOR GATE, C-MOS, 14PIN, TC74HC27AF(TP2)	1
IC 17	DA37451E111M	IC, SKBE, 8bit-MICROPROCESSOR, M37451E8-111FP	1
IC 18	DARH5RA45AAR	IC, VOLTAGE REGULATOR, 4.5V, RH5RA45AA-T2	1
IC 19	DAHC244AFTO	IC, OCTAL BUFFERS AND LINE DRIVERS C-MOS, 20-PIN, TC74HC244AF	1
IC 20	DAHC125AFTO	IC, QUAD TRI-STATE BUFFER, 14-PIN, C-MOS, TC74HC125AF(TP2)	1
IC 21	DAHC4066AFTO	IC, QUAD BILATERAL SWITCH, C-MOS, TC4066BP	1
IC 22	DFWP0030ZAY	IC, VOLTAGE DETECTOR, HYBRID	1
IC 23, 24, 25	DAUPC358GE2D	IC, OP AMP, UPC358GE2	3
IC 26, 27	DAHCO0AFTO	IC, QUAD 2-INPUT NAND GATES, C-MOS, 14-PIN, TC74HC00AF	2
IC 28	DAH74AFTO	IC, DUAL D-TYPE POSITIVE-EDGE-TRIGGERED FLIP-FLOP, TC74HC74AF-TP2	1
IC 29	DFWP0029ZAY	IC, DC-DC CONVERTER, HYBRID	1
IC 30	DARH5RA30AAR	IC, VOLTAGE REGULATOR, 3.5V, RH5RA30AA-T2	1
IC 31, 32, 33	DARH5VA45AAR	IC, RESET SIGNAL GENERATOR, RH5VA45AA, 4.5V	3
IC 34	DAS88501AFTW	IC, REGULATOR, S-88501AF-TB	1
IC 35	DARH5RA35AAR	IC, VOLTAGE REGULATOR, 3.5V, RH5RA35AA-T2	1
IC 36	DARH5RA40AAR	IC, VOLTAGE REGULATOR, 4.0V, RH5RA40AA-T2	1
IC 37	DAAC86SJLN	IC, EXCLUSIVE OR, C-MOS, 4-GATE	1
IC 38	DAHC32AFTO	IC, QUAD 2-INPUT OR GATES, C-MOS, 14-PIN, TC74HC32AF	1
IC 39	DAH74AFTO	IC, DUAL D-TYPE POSITIVE-EDGE-TRIGGERED FLIP-FLOP, TC74HC74AF-TP2	1
L 1-8	DDB5Z005-L	FERRITE BEAD	8
L 9-16	DDB5Z010-L	FERRITE BEAD	8
L 17-33	DDB5Z005-L	FERRITE BEAD	17
L 34	ELJFA101KF	FERRITE BEAD	1
L 35	DDB5Z005-L	FERRITE BEAD	1
L 36	DDB5Z007-L	FERRITE BEAD	1
L 37-39	DDB5Z005-L	FERRITE BEAD	3
L 40	DDB5Z007-L	FERRITE BEAD	1
L 41-48	DDB5Z005-L	FERRITE BEAD	8
L 49	ELJFA101KF	COIL	1
L 51	DDB8Z014-Y	FERRITE BEAD	1
L 52, 53	DDB5Z007-L	FERRITE BEAD	2
L 54	DDB5Z010-L	FERRITE BEAD	1
L 55	DDB6Z015-Y	FERRITE BEAD	1
Q 1	DETA144TKT97	TRANSISTOR, RESISTOR BUILT-IN, (2.9 x 1.6 x 1.1), Chip, DTA144TK	1
Q 3	DET1MH8T109	TRANSISTOR, Inverter Driver, Dual, (2.9 x 1.6 x 1.1), Chip, IMH8	1
Q 4	DETFMC3TA-E	TRANSISTOR, Switching, (2.9 x 1.6 x 1.1), Chip, FMC3	1
Q 5	2SK1582T2	TRANSISTOR, FET	1
Q 6	2SJ238TR	TRANSISTOR, FET	1
Q 7	2SA1037KT97R	TRANSISTOR, PNP TYPE, CHIP	1
Q 8	DETFMG1TA-E	TRANSISTOR, NPN TYPE, Inverter Driver, (2.9 x 1.6 x 1.1), Chip, FMG1	1
Q 9	2SK1764TR	TRANSISTOR, SI Nch MOS FET	1
Q10	2SJ238TR	TRANSISTOR, FET	1
Q11	2SJ182STR	TRANSISTOR, FET	1
Q12	2SJ214STR	MOSFET TRANSISTOR, P-ch FET	1
Q13, 14	DETFMG1TA-E	TRANSISTOR, NPN TYPE, Inverter Driver, (2.9 x 1.6 x 1.1), Chip, FMG1	2
Q15	DET1MT1T108	TRANSISTOR, Signal Amp, Dual, (2.9 x 1.6 x 1.1), Chip, IMT1	1
Q16, 17	DET1MX1TA-E	TRANSISTOR, Signal Amp, Dual, (2.9 x 1.6 x 1.1), Chip, IMX1	2
Q18	2SK1582T2	TRANSISTOR, FET	1
Q19	2SD1664RTP	TRANSISTOR, NPN TYPE, CHIP	1
Q20	2SJ220STR	TRANSISTOR, SI Pch MOS FET	1
Q21	2SJ238TR	TRANSISTOR, FET	1
Q22	2SB1181FQTAE	TRANSISTOR, PNP TYPE	1
Q23	2SB1260T10OR	TRANSISTOR, PNP TYPE, CHIP	1
Q24	DETC114EKT97	TRANSISTOR,	1
Q25	DETFMC3TA-E	TRANSISTOR, Switching, (2.9 x 1.6 x 1.1), Chip, FMC3	1
R 1, 2	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	2
R 3-5	DBJ6GMJ330VE	RESISTOR, Thick Film, Chip, 33ohm, +/-5%, 1/10W	3
R 6	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	1
R 7	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R 9	DBJ6GMJ104VE	RESISTOR, Thick Film, CHIP, 100Kohm, +/-5%, 1/10W	1
R 11	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1

REF. No. AND AREA	PART NO.	DESCRIPTION	QTY
R 12	DBJ6GMJ222VE	RESISTOR, Thick Film, CHIP, 2.2Kohm, +/-5%, 1/10W	1
R 13, 14	DBJ6GMJ561VE	RESISTOR, Thick Film, CHIP, 560ohm, +/-5%, 1/10W	2
R 15	DBJ6GF5601VE	RESISTOR, Thick Film, CHIP, 5.6Kohm, +/-1%, 1/10W	1
R 16	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R 17, 18	DBJ6GMJ821VE	RESISTOR, Thick Film, CHIP, 820ohm, +/-5%, 1/10W	2
R 19	DBJ6GMJ330VE	RESISTOR, Thick Film, Chip, 33ohm, +/-5%, 1/10W	1
R 20	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R 21	DBJ6GMJ474VE	RESISTOR, Thick Film, CHIP, 470Kohm, +/-5%, 1/10W	1
R 22-25	DBJ6GMJ330VE	RESISTOR, Thick Film, Chip, 33ohm, +/-5%, 1/10W	4
R 26, 27	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	2
R 28	DBJ6GMJ105VE	RESISTOR, Thick Film, Chip, 1Mohm, +/-5%, 1/10W	1
R 29	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	1
R 30, 31	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	2
R 32	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	1
R 33	DBJ6GMJ105VE	RESISTOR, Thick Film, Chip, 1Mohm, +/-5%, 1/10W	1
R 34	DBJ6GF7501VE	RESISTOR, Thick Film, Chip, 7.5Kohm, +/-1%, 1/10W	1
R 35	DBJ6GF1502VE	RESISTOR, Thick Film, Chip, 15Kohm, +/-1%, 1/10W	1
R 36	DBJ6GF1501VE	RESISTOR, Thick Film, Chip, 1.5Kohm, +/-1%, 1/10W	1
R 37	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R 38	DBJ6GMJ122VE	RESISTOR, Thick Film, Chip, 1.2Kohm, +/-5%, 1/10W	1
R 40	DBJ6GMJ393VE	RESISTOR, Thick Film, Chip, 39Kohm, +/-5%, 1/10W	1
R 41	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R 42	DBJ6GMJ683VE	RESISTOR, Thick Film, CHIP, 68Kohm, +/-5%, 1/10W	1
R 43	DBJ6GF2002VE	RESISTOR, Thick Film, CHIP, 20Kohm, +/-1%, 1/10W	1
R 44	DBJ6GF1203VE	RESISTOR, Thick Film, CHIP, 120Kohm, +/-10%, 1/10W	1
R 45	DBJ6GF2001VE	RESISTOR, Thick Film, CHIP, 2Kohm, +/-1%, 1/10W	1
R 46	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R 47	DBJ6GF1802VE	RESISTOR, Thick Film, CHIP, 18Kohm, +/-1%, 1/10W	1
R 49	ERJ6GEYF332V	RESISTOR, Thick Film, CHIP, 3.3Kohm, +/-1%, 1/16W	1
R 50	DBJ6GMJROOVE	JUMPER, 0ohm, Chip	1
R 51	DBJ6GMJ562VE	RESISTOR, Thick Film, CHIP, 5.6Kohm, +/-5%, 1/10W	1
R 52	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R 53	DBJ6GMJ273VE	RESISTOR, Thick Film, CHIP, 27Kohm, +/-5%, 1/10W	1
R 54	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	1
R 55	DBJ6GF1003VE	RESISTOR, Thick Film, CHIP, 100Kohm, +/-10%, 1/10W	1
R 56	DBJ6GMJ104VE	RESISTOR, Thick Film, CHIP, 100Kohm, +/-5%, 1/10W	1
R 57	DBJ6GMJ101VE	RESISTOR, Thick Film, CHIP, 100ohm, +/-5%, 1/10W	1
R 58	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R 59	DBJ6GMJ105VE	RESISTOR, Thick Film, Chip, 1Mohm, +/-5%, 1/10W	1
R 61	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	1
R 62	DBJ6GMJ513VE	RESISTOR, Thick Film, CHIP, 51Kohm, +/-5%, 1/10W	1
R 63	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R 64	DBJ6GMJ104VE	RESISTOR, Thick Film, CHIP, 100Kohm, +/-5%, 1/10W	1
R 65	DBJ6GMJ105VE	RESISTOR, Thick Film, Chip, 1Mohm, +/-5%, 1/10W	1
R 66, 67	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	2
R 68	DBJ6GMJ101VE	RESISTOR, Thick Film, CHIP, 100ohm, +/-5%, 1/10W	1
R 69	DBJ6GMJ105VE	RESISTOR, Thick Film, Chip, 1Mohm, +/-5%, 1/10W	1
R 70	DBJ6GMJ104VE	RESISTOR, Thick Film, CHIP, 100Kohm, +/-5%, 1/10W	1
R 71	DBJ6GMJ101VE	RESISTOR, Thick Film, CHIP, 100ohm, +/-5%, 1/10W	1
R 72	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R 73	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	1
R 74	DBJ6GMJ104VE	RESISTOR, Thick Film, CHIP, 100Kohm, +/-5%, 1/10W	1
R 75	DBJ6GMJ101VE	RESISTOR, Thick Film, CHIP, 100ohm, +/-5%, 1/10W	1
R 76, 77	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	2
R 78	DBJ6GMJ474VE	RESISTOR, Thick Film, CHIP, 470Kohm, +/-5%, 1/10W	1
R 79	DBJ6GMJ330VE	RESISTOR, Thick Film, Chip, 33ohm, +/-5%, 1/10W	1
R 80, 81	ERJ8GEYJ1R0V	RESISTOR, Thick Film, CHIP, 1.0ohm, +/-5%, 1/8W	2
R 82	DBJ6GMJ472VE	RESISTOR, Thick Film, CHIP, 4.7Kohm, +/-5%, 1/10W	1
R 83	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R 84, 85	DBJ6GMJ561VE	RESISTOR, Thick Film, CHIP, 560ohm, +/-5%, 1/10W	2
R 86	DBJ6GF1502VE	RESISTOR, Thick Film, Chip, 15Kohm, +/-1%, 1/10W	1
R 87	DBJ6GMJ104VE	RESISTOR, Thick Film, CHIP, 100Kohm, +/-5%, 1/10W	1
R 88, 89	DBJ6GMJ472VE	RESISTOR, Thick Film, CHIP, 4.7Kohm, +/-5%, 1/10W	2
R 90	DBJ6GMJ622VE	RESISTOR, Thick Film, CHIP, 6.2Kohm, +/-5%, 1/10W	1
R 91	DBJ6GMJ103VE	RESISTOR, Thick Film, CHIP, 10Kohm, +/-5%, 1/10W	1
R 92	DBJ6GMJ104VE	RESISTOR, Thick Film, CHIP, 100Kohm, +/-5%, 1/10W	1
R 93	DBJ6GMJ472VE	RESISTOR, Thick Film, CHIP, 4.7Kohm, +/-5%, 1/10W	1
R 94	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R 95	DBJ6GMJ472VE	RESISTOR, Thick Film, CHIP, 4.7Kohm, +/-5%, 1/10W	1

REF. No. AND AREA	PART NO.	DESCRIPTION	QTY
R 96, 97	DBJ6GMJ514VE	RESISTOR, Thick Film, CHIP, 510Kohm, +/-5%, 1/10W	2
R 98	DBJ6GF5603VE	RESISTOR, Thick Film, CHIP, 560Kohm, +/-1%, 1/10W	1
R 99	DBJ6GMJ274VE	RESISTOR, Thick Film, CHIP, 270Kohm, +/-5%, 1/10W	1
R100	DBJ6GF3303VE	RESISTOR, Thick Film, CHIP, 330Kohm, +/-1%, 1/10W	1
R101	DBJ6GMJ684VE	RESISTOR, Thick Film, CHIP, 680Kohm, +/-5%, 1/10W	1
R102, 103	DBJ6GMJ750VE	RESISTOR, Thick Film, CHIP, 75ohm, +/-5%, 1/10W	2
R104	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R105	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	1
R106	ERJ12YJ4R7H	RESISTOR, Thick Film, CHIP, 4.7ohm, +/-5%, 1/2W	1
R107	ERJ12YJ331H	RESISTOR, Thick Film, CHIP, 330ohm, +/-5%, 1/2W	1
R108	ERX1SZJR10P	RESISTOR, METAL FILM, 0.1 ohm, +/-5%, 1W	1
R109	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R113, 114	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	2
R115	DBJ6GMJ102VE	RESISTOR, Thick Film, CHIP, 1Kohm, +/-5%, 1/10W	1
R116	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R117	DBJ6GMJ273VE	RESISTOR, Thick Film, CHIP, 27Kohm, +/-5%, 1/10W	1
R118	DBJ6GMJ473VE	RESISTOR, Thick Film, CHIP, 47Kohm, +/-5%, 1/10W	1
R119	DBJ6GMJ471VE	RESISTOR, Thick Film, CHIP, 470ohm, +/-5%, 1/10W	1
R120	DBJ6GMJ472VE	RESISTOR, Thick Film, CHIP, 4.7Kohm, +/-5%, 1/10W	1
R121	DBJ6GMJ222VE	RESISTOR, Thick Film, CHIP, 2.2Kohm, +/-5%, 1/10W	1
R122	ERJ6ENF1801V	RESISTOR, Thick Film, CHIP, 1.8Kohm, +/-1%, 1/10W	1
R123	DBJ6GMJ562VE	RESISTOR, Thick Film, CHIP, 5.6Kohm, +/-5%, 1/10W	1
RA 1	EXBS8V103J	RESISTOR ARRAY, 10Kohm x 4	1
RA 2	EXBS8V330J	RESISTOR ARRAY, 33ohm x 4	1
RA 3-5	EXBS8V102J	RESISTOR ARRAY, 1Kohm x 4	3
RA 6	EXBS8V472J	RESISTOR ARRAY, 4.7Kohm x 4	1
RA 7	EXBS8V222J	RESISTOR ARRAY, 2.2Kohm x 4	1
RA 8, 9	EXBS8V103J	RESISTOR ARRAY, 10Kohm x 4	2
RA10-17	EXBS8V473J	RESISTOR ARRAY, 47Kohm x 4	8
SW1	DFSH1A21ZAXA	SWITCH, RESET	1
X1	DECU00032P1D	CRYSTAL, 32.768KHz,	1
X2	DECU24000P1H	CRYSTAL, 24MHz, FDC	1
X3	DECU10000P1H	CRYSTAL, 10MHz,	1
<b>LED/SWITCH PCB</b>			
E 3	DL3U40510CAA	Ass'y, PCB, LED/SWITCH	NLA 1
CN501	DFJPO7C78ZAO	CONNECTOR, 7-PIN, MALE	1
LD501-505	LN1361C-TR	LED, GREEN, RED	5
SW501	EVQPHPO3T	SWITCH,	1
<b>POWER/BATTERY LED PCB</b>			
E 4	DL3U20510CAA	Ass'y, PCB, POWER/BATT LED	NLA 1
CN502	DFJPO5C82ZAO	CONNECTOR, 5-PIN, MALE	1
LD506, 507	LN086WP38	LED, GREEN, RED	2
<b>CONTRAST CONTROL PCB</b>			
E 5	DL3U10484AAA	Ass'y, CONTRAST CONTROL, PCB	NLA 1
R901	DB02KF1052TE	RESISTOR, METAL, 10.5Kohm, +/-1%, 1/4W	1
VR901	DEVAI7B103A	RESISTOR, SEMI-FIXED,	1
TH901	DBT103J-U	THERMISTOR, 10Kohm, 0.3mA at 25 deg.C, TD5-031	1
CN901	DFJPO2C54ZAJ	CONNECTOR, 2-PIN, MALE	1
<b>TRACK BALL</b>			
E11	EMU-15901	Ass'y, TRACK-BALL	1
E11-1	DFWV65C0223	LID, TRACK-BALL	1
E11-2	DFWV65C0224	BALL, TRACK-BALL	1


## 6.6 Keyboard Parts Locations




## 6.7 Replacement Parts List (Keyboard)


REF.	PART NO.	DESCRIPTION	QTY
Keyboard for (M)			
E10	BSU54TM404BK	Ass'y, KEYBOARD(M)	1
1	DFWV70C8998	KEYTOP, Esc	1
2	DFWV70C8999	KEYTOP, F1	1
3	DFWV70C7000	KEYTOP, F2	1
4	DFWV70C7001	KEYTOP, F3	1
5	DFWV70C7002	KEYTOP, F4	1
6	DFWV70C7003	KEYTOP, F5	1
7	DFWV70C7004	KEYTOP, F6	1
8	DFWV70C7005	KEYTOP, F7	1
9	DFWV70C7006	KEYTOP, F8	1
10	DFWV70C7007	KEYTOP, F9	1
11	DFWV70C7008	KEYTOP, F10	1
12	DFWV70C7009	KEYTOP, F11	1
13	DFWV70C7010	KEYTOP, F12	1
14	DFWV70C7011	KEYTOP, NumLk	1
15	DFWV70C7012	KEYTOP, PrtSc SysRq	1
16	DFWV70C7013	KEYTOP, ScrLk Key Pad	1
17	DFWV70C7014	KEYTOP, Pause Break	1
18	DFWV70C7015	KEYTOP, ! 1	1
19	DFWV70C7016	KEYTOP, @ 2	1
20	DFWV70C7017	KEYTOP, # 3	1
21	DFWV70C7018	KEYTOP, \$ 4	1
22	DFWV70C7019	KEYTOP, % 5	1
23	DFWV70C7020	KEYTOP, ^ 6	1
24	DFWV70C7021	KEYTOP, & 7	1
25	DFWV70C7022	KEYTOP, * 8	1
26	DFWV70C7023	KEYTOP, ( 9	1
27	DFWV70C7024	KEYTOP, ) 0	1
28	DFWV70C7025	KEYTOP, -	1
29	DFWV70C7026	KEYTOP, + =	1
30	DFWV70C7027	KEYTOP, ←	1
31	DFWV70C7028	KEYTOP, Home	1
32	DFWV70C7029	KEYTOP, ⇐	1
33	DFWV70C7030	KEYTOP, Q	1
34	DFWV70C7031	KEYTOP, W	1
35	DFWV70C7032	KEYTOP, E	1
36	DFWV70C7033	KEYTOP, R	1
37	DFWV70C7034	KEYTOP, T	1
38	DFWV70C7035	KEYTOP, Y	1
39	DFWV70C7036	KEYTOP, U	1
40	DFWV70C7037	KEYTOP, I	1
41	DFWV70C7038	KEYTOP, O	1
42	DFWV70C7039	KEYTOP, P	1
43	DFWV70C7040	KEYTOP, { [	1
44	DFWV70C7041	KEYTOP, } ]	1
45	DFWV70C7042	KEYTOP,   \	1
46	DFWV70C7043	KEYTOP, PgUp	1
47	DFWV70C7044	KEYTOP, Caps Lock	1
48	DFWV70C7045	KEYTOP, A	1
49	DFWV70C7046	KEYTOP, S	1
50	DFWV70C7047	KEYTOP, D	1
51	DFWV70C7048	KEYTOP, F	1
52	DFWV70C7049	KEYTOP, G	1
53	DFWV70C7050	KEYTOP, H	1
54	DFWV70C7051	KEYTOP, J	1
55	DFWV70C7052	KEYTOP, K	1

REF.	PART NO.	DESCRIPTION	QTY
56	DFWV70C7053	KEYTOP, L	1
57	DFWV70C7054	KEYTOP, ; : +	1
58	DFWV70C7055	KEYTOP, " '	1
59	DFWV70C7056	KEYTOP, Enter	1
60	DFWV70C7057	KEYTOP, PgDn	1
61	DFWV70C7058	KEYTOP, Shift(L)	1
62	DFWV70C7059	KEYTOP, Z	1
63	DFWV70C7060	KEYTOP, X	1
64	DFWV70C7061	KEYTOP, C	1
65	DFWV70C7062	KEYTOP, V	1
66	DFWV70C7063	KEYTOP, B	1
67	DFWV70C7064	KEYTOP, N	1
68	DFWV70C7065	KEYTOP, M	1
69	DFWV70C7066	KEYTOP, < ,	1
70	DFWV70C7067	KEYTOP, > .	1
71	DFWV70C7068	KEYTOP, ? /	1
72	DFWV70C7069	KEYTOP, Shift(R)	1
73	DFWV70C7070	KEYTOP, ↑	1
74	DFWV70C7071	KEYTOP, End	1
75	DFWV70C7072	KEYTOP, Ctrl	1
76	DFWV70C7073	KEYTOP, Fn	1
77	DFWV70C7074	KEYTOP, Alt	1
78	DFWV70C7075	KEYTOP, ~	1
79	DFWV70C7076	KEYTOP, Ins	1
80	DFWV70C7077	KEYTOP, Del	1
81	DFWV70C7078	KEYTOP, ←	1
82	DFWV70C7079	KEYTOP, ↓	1
83	DFWV70C7080	KEYTOP, →	1
84	DFWV70C7081	KEYTOP, Space	1
E10-1	DFWV48C193Z	SWITCH, MEMBRANE	1
E10-2	DFWV65D0044	SPRING, RUBBER, KEYTOP	67
E10-3	DFWV71H0046	ROD, ENTER/SHIFT(L)	1
E10-4	DFWV71H0047	ROD, BACK SPACE	3
E10-5	DFWV71H0048	ROD, SPACE BAR	1
E10-6	DFWV50B0016	SCREW, KEYBOARD	23
E10-7	DFWV71H0049	ROD, Ctrl/Cplk/SHIFT(R)	3
E10-8	DFWV65C0219	PAD, KEYTOP	67
E10-9	DFWV65D0046	SPRING, RUBBER, KEYTOP, FUNCTION KEY	17
E10-10	DFWV65C0220	PAD, KEYTOP, FUNCTION KEY	17









**TANDY CORPORATION**  
**Fort Worth, Texas 76102**

9/92-Bry

MS2503573/G26-1661/62/63

Printed in U.S.A.

# Radio Shack<sup>®</sup> unlimited<sup>SM</sup>

**PURCHASER:**

NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

APT. NO. \_\_\_\_\_

CITY \_\_\_\_\_

STATE \_\_\_\_\_ ZIP \_\_\_\_\_

PHONE (      ) \_\_\_\_\_

**SHIP TO:**

NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

APT. NO. \_\_\_\_\_

CITY \_\_\_\_\_

STATE \_\_\_\_\_ ZIP \_\_\_\_\_

PHONE (      ) \_\_\_\_\_

CATALOG NO.	DESCRIPTION	QTY.	PRICE EACH

Fill out this form and give to any sales associate to complete your order. Sorry, we cannot ship to a P.O. Box

FO-800

## READ ME FIRST

All computer software is subject to change, correction, or improvement as the manufacturer receives customer comments and experiences. Radio Shack has established a system to keep you immediately informed of any reported problems, and the solutions. We have a customer service network including representatives in many Radio Shack Computer Centers, and a large group in Fort Worth, Texas, to help with any specific errors you may find in your use of this product. We will also furnish information on any improvements or changes that are "cut in" on later production versions.

To take advantage of these services, you must do three things:

- (1) Send in the postage-paid registration card included in this manual immediately. (Postage must be affixed in Canada.)
- (2) If you change your address, you must send us a change of address card (enclosed), listing your old address exactly as it is currently on file with us.
- (3) As we furnish updates, and you update your software, you must keep an accurate record of the current version numbers on the logs below. (The version number will be furnished with each update.)

Keep this card in your manual at all times, and refer to the current version numbers when requesting information or help from us. Thank you.

### APPLICATIONS SOFTWARE VERSION LOG

_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____

### OP. SYSTEM VERSION LOG

_____
_____
_____
_____