PC floppy	Motherboard		PC floppy
5V (power)	**5V**	**CORDDCPWR**	NC
5V (power)	**5V**	**A/B**	external drive switch GND?
PULLUP (5V?)	**/3OR5**	**/EFLOPPY**	external drive detected GND
32(SIDESEL)	**SIDESELECT**	**GND(signal)**	GND
30(RDATA)	**/FLOPPYRDATA**	**/WRITEPROTECT**	28(WPT/)
26(TRK0/)	**/TRK00**	**/HDDRIVE**	2(DENSEL)
24(WGATE/)	**/WRITEGATE**	**GND(signal)**	GND
22(WDATA/)	**/FLOPPYWDATA**	**TAPEDETECT**	NC
20(STEP/)	**/STEP**	**/DIRECTION**	18(DIR/)
10(MOTEA/) or 16(MOTEB/)	**/MOTOR2**	**/DISKCHANGE**	34(DSKCHG/)
14(DRVSA) or 12(DRVSB)	**/DRIVE2**	**LOWDENSITY**	NC
8(INDEX/)	**/FDDINDEX**	**GND**	GND (power)
bottom	**NC**	**GND**	GND (power)

13	**12**	**11**	**10**	**9**	**8**	**7**	**6**	**5**	**4**	**3**	**2**	**1**											
BLOCKED	**/LOWDENSITY**	**LOWDENSITY**	**/DISKCHANGE**	**/DIRECTION**	**TAPEDETECT**	**GND(signal)**	**/HDDRIVE**	**/WRITEPROTECT**	**GND**	**/EFLOPPY**	**A/B**	**CORDDCPWR**											
	CORDPWR	**/FDDINDEX**	**/DRIVE2**	**/MOTOR2**	**/STEP**	**/FLOPPYWDATA**	**/WRITEGATE**	**/TRK00**	**/FLOPPYRDATA**	**SIDESELECT**	**/3OR5**	**5V**											
	25	**24**	**23**	**22**	**21**	**20**	**19**	**18**	**17**	**16**	**15**	**14**											