
Guide To GRiD Documentation For The MS-DOS User

To set up and care for your GRiD Compass

- Read the **GRiD Compass Owner's Guide** shipped in the box with your GRiD Compass. Insert this guide in your MS-DOS binder for safe keeping.

For the New MS-DOS User

- Chapters 1 and 2 of **Using MS-DOS on the GRiD Compass** provide a quick overview of the steps required to get started with MS-DOS.
- Chapters 1 - 3 of the **Microsoft MS-DOS User's Guide** introduce you to general MS-DOS concepts and terminology.
- If you are currently a GRiD/OS user, be sure to read Chapter 5 of **Using MS-DOS on the GRiD Compass** for specific information about how to reformat your storage devices and partition your hard disk for MS-DOS.

For the Experienced MS-DOS User

- Chapters 3 - 6 of **Using MS-DOS on the GRiD Compass** describe the MS-DOS features unique to the GRiD Compass.

Running MS-DOS Applications

- Chapter 7 of **Using MS-DOS on the GRiD Compass** describes MS-DOS applications specifically customized to run on the GRiD Compass, including 1-2-3, WordStar, and Multiplan.
- Chapters 8 and 9 of **Using MS-DOS on the GRiD Compass** provide detailed information on customizing and installing other MS-DOS applications.
- Refer to each application program's reference manual for additional details.